

DUCAR

Parts diagram




The model may differ slightly from the picture

DUEDGPW1500 DUCAR Pressure washer

PRESSURE WASHER DIAGRAM


DGPW1500



	Part number	Part name	Quantity
1	DUP120007910004	DH79 ENGINE	1
2	DUP815121-010	FRAME	1
3	DUP90024	SELF-LOCKING NUT M6	7
4	DUP813015	RUBBER FOOT	4
5	DUP92026	BOLT M6X40	3
6	DUP813026	ANTIVIBRATION RUBBER	4
7	DUP90018	NUT M8	4
8	DUP92027	BOLT WITH DISC M6*45	4
9	DUP94025	FLAT WASHER	1
10	DUP814027	SPRAY GUN HOOK	1
11	DUP814020	ATTACHMENT LINK	1
12	DUP94221	FLAT WASHER	6
13	DUP815465-010	HANDLE, FRAME	1
14	DUP296502	CRANKSHAFT FLAT KEY	1
15	DUP91345	BOLT M8X20	4
16	DUP810019	WATER PUMP ASSEMBLY	1
17	DUP817117-219	SPRAY GUN	1
18	DUP817059	WAND	1
19	DUP811518	HIGH PRESSURE HOSE	1
20	DUP811002	SUCTION HOSE	1
21	DUP817061	SUCTION FLUID MESH	1
22	DUP8811	O-RING	2
23	DUP813040	HANDLEBAR GRIP	1
24	DUP816006	DETENT SPRING	2
25	DUP94223	FLAT WASHER	4

ENGINE DIAGRAM

DGPW1500



	Part number	Part name	Quantity
1	DUP210203	CRANKCASE	1
2	DUP93005	BALL BEARING	1
3	DUP93502	OIL SEAL	2
4	DUP224301	GOVERNOR ASSEMBLY	1
5	DUP223901	SHAFT, GOVERNOR ARM	1
6	DUP96803	WASHER,GOVERNOR ARM SHAFT	1
7	DUP243902	PIN, LOCK	1
8	DUP91816	BOLT, DRAIN PLUG	1
9	DUP94007	WASHER, DRAIN PLUG	1
10	DUP241805	RETURNER, INTAKE VALVE	1
11	DUP210801	CLIP	2
12	DUP240904	DOWEL PIN, CASECOVER	2
13	DUP211202	PISTON	1
14	DUP211602	SCRAPER RING SET ,PISTON	1
15	DUP221501	ROD ASSEMBLY, CONNECTING	1
16	DUP225501	PIN, PISTON	1
17	DUP221301	CLIP, PISTON	2
18	DUP220101	COVER ASSEMBLY, CRANKCASE	1
19	DUP93019	BALL BEARING	1
20	DUP221004	CYLINDER HEAD	1
21	DUP221701	VALVE, IN	1
22	DUP225902	VALVE EXHAUST	1
23	DUP226001	SPRING, VALVE	2
24	DUP241801	SEAT, VALVE SPRING,IN	2
25	DUP222201	PLATE, PUSH ROD GUIDE	1
26	DUP222101	ROCKER ASSY	2
27	DUP91023	BOLT, STUD	2
28	DUP91007	BOLT, STUD	2
29	DUP212803	CARBURETOR ASSEMBLY	1
30	DUP95451L	FUEL LINE 4x8x200mm	1
31	DUP94404	CLIP, FUEL LINE	1
32	DUP210319	CRANKSHAFT ASSEMBLY	1
33	DUP226101	LIFTER, VALVE	2
34	DUP96027	PACKING, CASECOVER	1
35	DUP222003	CAMSHAFT ASSEMBLY	1
36	DUP240901	PIN, DOWEL	2
37	DUP91333	BOLT M6X28	6
38	DUP91331	BOLT M6X25	2
39	DUP96024	GASKET, CYLINDER HEAD	1
40	DUP91352	BOLT M8X50	4
41	DUP97101	SPARK PLUG	1

42	DUP221901	ROD, PUSH	2
43	DUP220504	WIND DEFLECTOR	1
44	DUP91325	BOLT M6X12	16
45	DUP96045	PACKING, HEADCOVER	1
46	DUP241111	COVER COMP, CYLINDER HEAD	1
47	DUP220502	WIND SHIELD, LH	1
48	DUP220503	WIND SHIELD, RH	1
49	DUP220401	FLYWHEEL ASSEMBLY	1
50	DUP224601	FAN, RECOIL STARTER	1
51	DUP224501	PULLEY, STARTER	1
52	DUP90014	NUT M12	1
53	DUP97507	IGNITION COIL ASSEMBLY	1
54	DUP96032	PACKING, INTAKE	2
55	DUP222301	INSULATOR, CARBURETOR	1
56	DUP222701	ROD, GOVERNOR	1
57	DUP224202	SPRING, THROTTLE RETURN	1
58	DUP90016	NUT M6	4
59	DUP224001	GOVERNOR ARM	1
60	DUP224710-175	RECOIL STARTER ASSEMBLY	1
61	DUP224402	SHROUD ASSEMBLY, UPPER	1
62	DUP96035	GASKET, AIR CLEANER	1
63	DUP95602	TUBE, BREATHER	1
64	DUP222901	AIR CLEANER ASSEMBLY	1
65	DUP224105	SPRING, GOVERNOR	1
66	DUP245104	AMPLIFIER	1
67	DUP225601-138	DIPSTICK	1
68	DUP90011	NUT M8	2
69	DUP94206	SPRING WASHER 8	2
70	DUP96033	PACKING, EXHAUST	1
71	DUP223703	MUFFLER COMP	1
72	DUP245205	SWITCH ASSEMBLY	1
73	DUP213102L-175	FUEL TANK ASSEMBLY	1
74	DUP213601	FUEL TANK CAP COMP	1
75	DUP225102	SWITCH ASSEMBLY, OIL LEVEL	1
76	DUP94403	CLIP, FUEL LINE	1
77	DUP91303	BOLT M6X12	2