

DUCAR


Diagramme de pièces *Parts diagram*



Le modèle peut différer légèrement de la photo / *The model may differ slightly from the picture*

DLG4000iSE dual fuel **Génératrice propane et essence** ***Propane and gasoline generator***

DLG4000iSE



Spare parts for the DLG4000iSE inverter dual fuel generator			
NO.	Code	Description	Qty
1	503001	BRACKET	1
2	503002	BRACKET	1
3	503003	BRACKET	1
4	90027	SQUARE NUT	8
5	503004	CUSHION	4
6	90044	NUT M8	14
7	91325	BOLT M6X12	29
8	503005-026	LEFT SKELETON	1
9	503006	UPRIGHT	1
10	503007	UPRIGHT	2
11	503008	BRACKET	2
12	503009-052	HANDLE	2
13	503010L	FUEL TANK	1
14	500008	FUEL TANK CUSHION B	2
15	503011	BRACKET	1
16	503042	BRACKET	1
17	503409	INVETER	1
18	503013	BRACKET	1
19	91322	BOLT M5×12	5
20	91345	BOLT M8X20	4
21	503478	PANEL FRONT COVER	1
22	503017	BRACKET	1
23	503062	FUEL SWITCH	1
24	503018L	FUEL HOSE CLIP $\Phi 4 \times \Phi 10 \times \Phi 6 \times \Phi 12-95L$	1
25	503019L	FUEL HOSE CLIP $\Phi 4 \times \Phi 10 \times \Phi 6 \times \Phi 12-55L$	1
26	503020L	FUEL HOSE CLIP $\Phi 4 \times \Phi 10-194L$	1
27	503044	CLIP	1
28	503021-026	RIGHT SKELETON	1
29	503022-026	OBSERVATION COVER	1
30	503023	AXLE PIN	1
31	511019	BATTERY	1
32	599606	BATTERY TIE	1
33	503048	DC VOLTAGE REGULATOR	1
34	503123	KNOB	1
35	500068	HANDLE BAFFLE PLUG	12
36	500060	LOCK CLIP M6	17
37	503025	PLUG	2
38	503026	CUSHION	2
39	503027	MUFFLER BAFFLE	1
40	503028	FUEL TANK CAP	1
41	503029	OIL CHANNEL	1
42	503067	BLIND RIVET	3
43	503031	WHEEL	2

44	503032	WHEEL COVER	2
45	500108	MUFFLER EXHAUST SEALING STRIP	1
46	503033	PULL ROD HOLDER	1
47	503034	FUEL HOSE CLIP	4
48	503035	PULL ROD	1
49	503036-052	HANDLE DECORATIVE BOARD	1
50	500017	HANDLE COVER	1
51	91825	BOLT M5X12	6
52	503038-026	TOP COVER	1
53	503039-026	LEFT PANEL	1
54	503040	COVER	1
55	505027	WIRE SLEEVE	1
56	95921	CONNECTING PIPE	1
57	503045	BOTTOM PLATE	1
58	518801	FILTER	1
59	503077	FILTER	1
60	94409	FUEL HOSE CLIP	2
61	500018	HANDLE	1
62	500044	SHORT WIRE	2
63	92014	SCREW ST4.2*13	3
64	91348	BOLT M8X35	6
65	94022	STEEL WASHER	4
66	94249	FLAT WASHER	3
67	92097	HEX FLANGE SCREW M6X20	8
68	503165	BATTERY CABLE	1
69	503398	DEPUTY WIRING HARNESS	1
70	94003	TOOTH WASHER	4
71	503473	PANEL ASSEMBLY	1
72	500011	FUEL SWITCH HOLDER	1
73	92032	SCREW M4*16	1
74	90010	NUT M6	1
75	91330	BOLT M6X20	6
76	91397	BOLT M6X20	4
77	96801	FUEL TANK WASHER	4
78	92078	CROSS RECESSED PAN HEAD BOLT M6X16	25
79	500007	FUEL TANK CUSHION A	2
80	92079	STOP BOLT M6X16	4
81	503052	BASE OIL COVER	1
82	503053	LIMIT BLOCK	2
83	500321	AXLE WILD CARD	2
84	91334	BOLT M6X30	6
85	110022530007	ENGINE ASSEMBLY DHLG225	1
86	503270	CHOKE LEVEL	1
87	500003	STEEL BALL	1
88	500012	SPRING	1

89	500242	CABLE TRAY	1
90	94218	FLAT WASHER $\phi 4$	1
91	94402	FUEL HOSE CLIP $\phi 8.5$	2
92	503082	BELLOW	2
93	503310	KNOB PLUG	1
94	503135	GAS CONTROL LINE	1
95	503131	UPPER COVER	1
96	503134	GEAR	1
97	503133	GEAR	1
98	92007	SCREW M4*8	4
99	503132	LOWER LID	1
100	503129	SWITCH AXIS	1
101	92019	SCREW M4*16	2
102	503130	O-RING	2
103	503128	TEE	1
104	503126	INTAKE CONNECTOR	1
105	503199	JACKET	1
106	503136	PLUG	1
107	50280014	PRESSURE REDUCING VALVE	1
108	545332	PRESSURE REDUCING VALVE	1
109	96120	GASKET	1
110	503127	OURLET CONNECTOR	1
111	517907	LOW PRESSURE HOSE	1

L'assemblage de tuyaux peut se commander en ensemble qui comprend les pièces suivantes:
The Hose assembly can be ordered as a kit which includes the following parts:

107	50280014	PRESSURE REDUCING VALVE	1
108	545332	PRESSURE REDUCING VALVE	1
109	96120	GASKET	1
110	503127	OURLET CONNECTOR	1
111	517907	LOW PRESSURE HOSE	1

Le numéro de pièce pour commander cet ensemble est le DUP100010008
The part number to order this kit is DUP100010008