


DUCAR

Equipment parts manual

Model : DUED4000i
4000W inverter generator



Picture may not reflect the exact model



No.	Code	Description	Qty
1	DUP503001	BRACKET	1
2	DUP503002	BRACKET	1
3	DUP503003	BRACKET	1
4	DUP503745	LEFT CONNECTION PLATE	2
5	DUP503004	ISOLATOR	4
6	DUP90044	NUT M8	14
7	DUP91325	BOLT M6X12	37
8	DUP503731-175	LEFT FRAME	1
9	DUP503739	FRONT HANDLE LEFT BRACKET	1
10	DUP503740	FRONT HANDLE RIGHT BRACKET	1
11	DUP503741	REAR HANDLE LEFT BRACKET	1
12	DUP503743-052	HANDLE	2
13	DUP503774	FUEL TANK	1
14	DUP500008	FUEL TANK ISOLATOR B	2
15	DUP503742	REAR HANDLE RIGHT BRACKET	1
16	DUP503744	FUEL TANK CONNECT BRACKET	2
17	DUP503409	INVETER MODULE	1
18	DUP503013	BRACKET	1
19	DUP91322	BOLT M5×12	4
20	DUP504237	CLIP	6
21	DUP503736	CONTROL PANEL REAR COVER	1
22	DUP503017	BRACKET	1
23	DUP503062	FUEL SWITCH	1
24	DUP503772	FUEL PIPE Φ4XΦ10XΦ6XΦ12-89L	1
25	DUP503773	FUEL PIPE Φ4XΦ10XΦ6XΦ12-45L	1
26	DUP503020L	FUEL PIPE Φ4XΦ10-194L	1
27	DUP503044	CLIP	1
28	DUP503732-175	RIGHT FRAME	1
29	DUP503733-175	OBSERVATION COVER	1
30	DUP503023	AXLE	1
31	DUP511019	BATTERY	1
32	DUP599606	BATTERY BANDGE	1
33	DUP503048	DC VOLTAGE REGULATOR	1
34	DUP503024	KNOB	1
35	DUP500068	HANDLE PANEL PLUG	5
36	DUP500060	CLIP M6	27
37	DUP503025	PLUG	2
38	DUP503026	ISOLATOR	2
39	DUP503738	MUFFLER COVER	1
40	DUP503028	FUEL TANK CAP	1
41	DUP503029	FUEL SLOT	1
42	DUP500661	BLIND RIVET	3

43	DUP503031	WHEEL	2
44	DUP503032	WHEEL COVER	2
45	DUP500108	MUFFLER SEALING GASCKET	1
46	DUP503033	PULL ROD SET	1
47	DUP94402	FUEL HOSE CLIP	2
48	DUP503035	PULL ROD	1
49	DUP503036-052	HANDLE DECORATIVE BOARD	1
50	DUP500017	HANDLE COVER	1
51	DUP91825	SCREW & WASHER M5 X 12	6
52	DUP503734-175	TOP COVER	1
53	DUP503730-175	LEFT PANEL	1
54	DUP503737	COVER	1
55	DUP500012	SPRING	1
56	DUP500003	STEEL BALL	1
57	DUP503735	BOTTOM PLATE	1
58	DUP518801	FILTER	1
59	DUP503077	FILTER	1
60	DUP500333	CABLE	1
61	DUP500018	HANDLE	1
62	DUP500044	SHORT CIRCUITING WIRE	2
63	DUP95921	TUBE,BREATHER	1
64	DUP91348	BOLT M8X35	6
65	DUP94022	METAL WASHER	4
66	DUP94217	FLAT WASHER	3
67	DUP92097	SCREW M6X20	8
68	DUP503165	BATTERY CABLE	1
69	DUP503791	DEPUTY WIRING HARNESS	1
70	DUP94003	TOOTH WASHER	4
71	DUP503893	CONTROL PANEL ASSEMBLY	1
72	DUP500011	OIL SWITCH HOLDER	1
73	DUP92032	SCREW M4X16	1
74	DUP91329	BOLT M6X16	12
75	DUP503746	RIGHT CONNECTION PLATE	2
76	DUP91397	BOLT M6X20	4
77	DUP96801	FUEL TANK WASHER	4
78	DUP92078	BOLT M6X16	19
79	DUP500007	FUEL TANK ISOLATOR A	2
80	DUP92079	BOLT M6X16	1
81	DUP503052	BASE OIL CAP	1
82	DUP503053	BLOCK	2
83	DUP500321	WHEEL AXLE CLIP	2
84	DUP91334	BOLT M6X30	4
85	DUP110022520103	ENGINE ASSEMBLY	1
86	DUP94411	FUEL HOSE CLIP $\Phi 11 \times 0.8$	2

87	DUP503082	HOSE	1
88	DUP503310	KNOB PLUG	1
89	DUP92018	SRREW M4*12	3
90	DUP503782	FUEL OUTLET	1
91	DUP94405	FUEL HOSE CLIP Ø11.5	2
92	DUP94403	FUEL HOSE CLIP Ø7.5	2
93	DUP91345	BOLT M8*20	4
94	DUP599601	METAL CLIP	2
95	DUP91331	BOLT M6X25	2
96	DUP90016	NUT M6	1
97	DUP500242	CABLE TRAY	1