

DUCAR


Engine parts manual

Model : DUETBC261S
Straight brushcutter-25.4CC



Picture may not reflect the exact model

ENGINE



No.	Part number	Description	Qty
1	GB/T2671.2	screw M5x12	3
2	C26.1110.0000	starter assembly	1
3	C26.1110.0200	start cover	1
4	A25.0110.0101	eyelet	1
5	A25.0110.0005	starter rope 2,5x800	1
6	A62.0110.0002	starter grip	1
7	C26.1110.0002	coil spring	1
8	C26.1110.0001	start pulley	1
9	C26.1110.0003	spring. Start	1
10	C26.1110.0004	ratchet wheel	1
11	GB/T97.1	plate washer	1
12	GB/T845	ST screw 4.8x16	1
13	C26.0101.0200	start reel	1
14	GB/T97.1	washer 8	1
15	A38.0302.0200	OIL-SEAL 12x22x7	1
16	C26.0102.0002	crank case RH side	1
17	C26.0102.0003	gasket \ crank case	1
18	GB/T276-20061619	bearing 6001	2
19	C26.1103.0100	crank shaft assembly	1
20	GB/T1099	key 3x3.5x10	1
21	C26.0103.0200	bearing 6001 8×11×11	1
22	A36.0103.0003	circlip \ Piston pin	2
23	B25.0103.0002	piston pin	1
24	B25.0103.0200	piston	1
25	B25.0103.0001	piston ring	2
26	C26.0101.0004	gasket \ cylinder	1
27	C26.1101.0001	cylinder w/butterfly valve	1
28	GB/T2671.220060868	screw M5x20	4
29	A45.0106.0500	Spark Plug CJ-7Y	1
30	GB/T845	ST screw 4.2x8	2
31	C26.1401.0004	Bouclier	1
32	GB/T845-20055741	ST screw 4.2x10	2
33	C26.1401.0003	couvert	1
34	GB/T845-20051824	ST screw 4.8x16	1
35	C26.1401.0001	top housing	1
36	C26.0106.0200	wire	1
37	C43.1106.0001	Spark Plug cover	1
38	C26.1106.0200	ignition	1
39	GB/T2671.220060868	screw M5x20	2
40	GB/T119.2	pin 5x10	2
41	C26.0102.0001	crank case LH side	1

No.	Part number	Description	Qty
42	GB/T2671.220061082	screw M5x25	3
43	A38.0302.0200	OIL-SEAL 12x22x7	1
44	C26.1106.0400	magneto rotor	1
45	GB/T6177.220054557	flange nut M8x1	1
46	B25.0101.0011	flat washer	2
47	C26.1101.0200	clutch assembly	1
48	B25.0101.0010	washer 8	2
49	B25.0101.0009	bolt \ clutch	2
50	GB/T119.2	pin ϕ 4x10	2
51	C26.1102.0001	fan cover	1
52	GB/T2671.220060868	screw M5x20	4
53	C26.1108.0100	clutch durm assembly	1
53	G26.0108.0100	clutch durm assembly	1
54	GB/T893.1-20054564	circlip 35	1
55	GB/T276	bearing 6202-2z 15x35x11	1
56	GB/T894.1-20061548	circlip 15	1
57	C26.1108.0001	clutch drum housing	1
58	GB/T2671.220060988	screw M6x20	4
59	C43.0108.0002	Shock absorber bushing	1
60	C43.0108.0004	clamp RH	1
61	C43.0108.0003	clamp LH	1
62	GB/T2671.220061082	screw M5x25	2
63	GB/T2671.220060990	screw M5x12	1
64	GB/T2671.220061129	screw M5x52	2
65	C26.1401.0002	muffler cover	1
66	G26.1212.0301	eyelet	2
67	C26.1405.0100	muffler	1
68	C26.1101.0005	gasket \ muffler	1
69	C26.0101.0006	gasket \ muffler	1
70	GB/T2671.220061134	screw M4x12	2
71	C26.1101.0007	gasket, air inlet pipe	1
72	C26.1101.0100	admitting pipe	1
73	C43.1101.0007	gasket, muffler	1
74	GB/T818	head screw M4x6	1
75	GB/T2671.220060868	screw M5x20	2
76	C26.1101.0004	gasket \ carburetor	1
77	C26.1101.0300	carburetor	1
78	C26.1104.0000	Air filter assembly	1
79	C26.1104.0001	Air filter base	1
80	GB/T2671.220061025	screw M5x45	2
81	C26.1104.0003	Filter, cartridge	1

No.	Part number	Description	Qty
82	C26.1104.0002	air filter cover	1
83	C43.1107.0101	fuel tank cover	1
84	C43.1107.0103	gasket rubber	1
85	C43.1107.0102	plate	1
86	C26.1107.0001-1	fuel tank	1
87	C43.1107.0002	ring, rubber	4
88	C26.1101.0003	fuel tank housing	1
89	GB/T2671.220061082	screw M5x25	4
90	A45.0111.0200	balancer	1
91	C43.1107.0006	air tube, EPA	1
92	C43.1107.0004	fuel line, EPA	1
93	C43.1107.0005	Oil tube, EPA	1
94	C43.1107.0003	retainer . fuel tube	1
95	A45.0102.0103	fuel line clamp spring	1
96	A38.0311.0500	filter fuel	1
97	C26.1105.0301	heat shield	1
98	E44.0110.004	sleeve, heat shield	1
99	GB/T845-20051789	self-tapping screw ST4x5	1