


DUCAR

Equipment parts manual

Model : DUESB1534T
Snowblower




Picture may not reflect the exact model



No.	Part number	Description	Qty
1	DUPS07*00656	jam nut M8	6
2	DUPKC55-10	right gimbal	1
3	DUPGB/T 6171-2000	nut M8x1	1
4	DUPKC26-04A	gear connector bar	1
5	DUPGB/T 889.1-2000	nut M8	5
6	DUPS07*00447	Concave gasket / 8*22*2	4
7	DUPKC30-05A	Armrest aluminum pad	2
8	DUPGB/T12-1988	bolts M8X55	4
9	DUPGB/T6563-2014	Hexagon head combination bolts M6X16	4
10	DUPKC30A-04A	Belt cover	1
11	DUPKC30A-07	Belt rod	1
12	DUPKC42A-03A	chute assebmly	1
13	DUPKC55-24	Snow shovel	1
14	DUPKC55-15	Helical bracket washers	1
15	DUPKC26-11	Long washers	1
16	DUPKC26-14	Hollow worm	1
17	DUPKC26-12	Mandrel	1
18	DUPKC26-15	Lower connection tube	1
19	DUPGB/T 879-2000	Elastic cylindrical pin 3 * 18	2
20	DUPKC26-16	Rotating frame cover	1
21	DUPGB/T9074.17-1994	screw M6X16	2
22	DUPKC26-10A	Rotating frame	1
23	DUPGB/T12-1988	bolt M8X16	3
24	DUPGB/T889.1-2000	hexagon lock nut M8	3
25	DUPGB/T 96.2-2002	washer C6	2
26	DUPKC26-17	friction pad	1
27	DUPKC26-18	friction spring	1
28	DUP4LXP900	belt	2
29	DUPGB/T9074.17-1994	bolt M8x20	2
30	DUPGB/T 96.2-2002	washer C8	2
31	DUPKC30-17	cable holder	1
32	DUPKC30A-08	belt cover washer	2

HANDLE




HANDLE

No.	Part number	Description	Qty
1	DUPKC30-03C-01R	upper handle (right)	1
2	DUPKC30-03-02	panel	1
3	DUPGB/T899.1-2000	nut M8	10
4	DUPKC30-03-44R	right pulley set	1
5	DUPGB/T12-1988	bolt M8x40	4
6	DUPGB/T5780-2000	bolt M6x20	2
7	DUPKC21-02-2	small shaft sleeve	2
8	DUPKC40-28	pulley	2
9	DUPKCA28-04-03	handle seat	2
10	DUPGB/T12-1988	bolt M8x45	2
11	DUPKC30-03-49	long cable	2
12	DUPGB/T12-1988	bolt M8x35	2
13	DUPS03*00493	B pin ϕ 1.5X25	4
14	DUPKC30-03-09	gear handle lever	1
15	DUPGB/T41-2000	nut M10	2
16	DUPKC30-03-2(M4)	gear handle	2
17	DUPKC30-03-11GGP	deflector handle lever	1
18	DUPGB/T 6183.1-2000	jam nut M6	4
19	DUPKC30-03-45	spring	2
20	DUPKCA28-04-14	short rod	1
21	DUPKCA28-04-04	right control lever	1
22	DUPKC55-03-15	rubber pad	2
23	DUPGB/T5287-2002	washer 8	2
24	DUPGB/T 70.1-1985	screw M8x150	1
25	DUPKCA28-04-17	stopper	1
26	DUPKC30-03-50	pin	2
27	DUPKCA28-04-16	cam	1
28	DUPKC55-03-11	stopper spring	1
29	DUPGB/T 70.1-1985	screw M8x60	1
30	DUPKCA28-04-08	long rod	1
31	DUPGB/T 12618-1990	rivet 4x10	4
32	DUPKC90-04-04A	heated handle	2
33	DUPKCA28-04-10	left control lever	1
34	DUPGB/T899.1-2000	jam nut M6	2
35	DUPKC55-03-05-6	short bushing	2
36	DUPKC30-03-14	input wire	1
37	DUPASW-07D	switch	2
38	DUPKC30A-05-4	deflector cable	1
39	DUPKCD26-06-2	spring	1

HANDLE

No.	Part number	Description	Qty
40	DUPKC30-03-44L	left pulley seat	1
41	DUPGB/T70.1-1985	screw M5x35	2
42	DUPKC30-03-08	differential handle	1
43	DUPGB/T 889.1-2000	jam nut M6	1
44	DUPGB/T95-2002	flast washer 6	1
45	DUPKC30-03-06	handle bolt	1
46	DUPKC30-03-05	differential handle seat	1
47	DUPKC30-02-06B	differential cable	1
48	DUPKC30-03-32	rotating handle	1
49	DUPKC30-03-31	rubber pad	10
50	DUPKC30-03-23	lower fixing seat for rotating lever	1
51	DUPKC30-03C-01L	upper handle (left)	1
52	DUPKC30-03-22B	flexible shaft	2
53	DUPGB/T 818-2000	screw M6x10	2
54	DUPGB/T95-2002	flat washer 6	2
55	DUPKC30-03-24	decoration plate for light	1
56	DUPGB/T9074.17-1988	bolt M6x16	2
57	DUPKC30-03-26	cover	1
58	DUPGB/T 889.1-2000	jam nut M6	2
59	DUPKC21-03-15	LED light	1
60	DUPGB/T846-1985	screw ST3.5x16-F	2

TRANSMISSION



TRANSMISSION

No.	Part number	Description	Qty
1	DUPKC90-02-21A	handlebar	1
2	DUPKC55-02-25A	handle connecting plate	2
3	DUPGB/T9074.17-1988;M10X45	Bolt M10x45	2
4	DUPGB/T5780-2000;M6X16	Bolt M6x16	8
5	DUPKC30A-02-30	strut	2
6	DUPKC30A-02T-01	cover 2	1
7	DUPGB/T5780-2000;M6X20	bolt M6x20	1
8	DUPKCM24-02C-19	pulley seat	1
9	DUPKC21-02-2	small shaft sleeve	1
10	DUPKC21-02C-01	short wire	1
11	DUPKC40-28	pulley	1
12	DUPGB/T899.1-2000;M6	jam nut M6	1
13	DUPKC30A-02-02	connecting plate	1
14	DUPGB/T9074.17-1988;M8X20	bolt M8X20	4
15	DUPGB/T5780-2000;M8X40	bolt M8X40	4
16	DUPS07*00143	washer 24*8*2	4
17	DUPKC30A-02-29	enging plate	1
18	DUPDIN6927	jam nut M8	4
19	DUPLC180FDS	engine	1
20	DUP3LXP870	belt	1
21	DUPKC30A-02-03	drive wheel	1
22	DUPKC21-02-36	washer	4
23	DUPKC90-02-16	drive pulley 2	1
24	DUPGB/T5287-2002;8	washer 8	1
25	DUPGB/T5786-2000; 5/16-24*1 1/4	bolt 5/16-24*1 1/4	1
26	DUPKC30A-02-04A	transmission box assembly	1
27	DUPGB/T9074.17-1988;M6X20	bolt M6x20	2
28	DUPKC30-02-12	shift connector	1
29	DUPKC90-02-07	plastic sleeve	3
30	DUPKC30A-02T-02	cover 3	1
31	DUPKC55-02-05	shift fork	1
32	DUPGB/T9074.17-1988;M6x16	bolt M6X16	13
33	DUPKC30A-02-05	bearing seat	2
34	DUPGB/T276-1997;6200	ball bearing 6200	4
35	DUPGB/T894.1-1986;25	circlip 25	1
36	DUPKC21-02-13	shift bearing	1
37	DUPKC30A-02-06	sleeve 15x20x15	1
38	DUPKC21-02-12B	rubber wheel seat	1
39	DUPKC30A-02-07	small gear	1


TRANSMISSION

No.	Part number	Description	Qty
40	DUPKC21-02-11A	rubber wheel	1
41	DUPKC30A-02-08	sleeve 18x23x18	1
42	DUPKC55-29	B pinchcock	1
43	DUPKC30A-02-9	hexagon shaft	1
44	DUPKC30A-02-10-2	transit shaft	1
45	DUPKC30A-02T-3	chain wheel	1
46	DUPKC30A-02-11	small chain wheel	1
47	DUPKC30A-02-12	sleeve 12x15x8	1
48	DUPGB/T1243-1997;085-26	chain 085-26	1
49	DUPKC30-02-16A	shaft sleeve	2
50	DUPGB/T9074.17-1988;M8X16	bolt M8x16	4
51	DUPKC90-02-11	bearing seat	2
52	DUPGB/T899.1-2000	jam nut M8	4
53	DUPGB/T899.1-2000;M8	ball bearing 6205	2
54	DUPKC30A-02-14	shaft sleeve 25x34x16	1
55	DUPKC30A-02-15	differential	1
56	DUPKC30A-02-16	short semi-shaft	1
57	DUPGB/T1095-2003;6X4X45	flat key 6x4x45	2
58	DUPKC30A-02-17	bronze sleeve 1	1
59	DUPKC30A-02-18	fork plate	1
60	DUPKC30-02-07	auxiliary differential part	1
61	DUPKC30-02-05	big spring	1
62	DUPKC30-02-06B	differential cable	1
63	DUPKC30A-02-19	bronze sleeve 2	1
64	DUPKC30A-02-20	long shaft	1
65	DUPKC30A-02-31	tension connector	1
66	DUPGB/T848-2002;¢12	flat washer;¢12	1
67	DUPGB/T955-1987;¢13	spring washer ¢13	1
68	DUPKC21-02C-09	fixing block	1
69	DUPGB/T5780-2000;M8x30	bolt M8X30	1
70	DUPKC55-02-21A	small tension pulley	1
71	DUPKC21-02C-10	small tension plate	1
72	DUPGB/T12-1988;M8X45	bolt M8x45	1
73	DUPKC30A-02A-5	big tension combination	1
74	DUPKC55-01-24	bushing	1
75	DUPKC55-01-27	big tension pulley	1
76	DUPKC55-01-26	pad	1
77	DUPKC21-02C-13	belt pulley	1
78	DUPGB/T9074.17-1988;M6x20	bolt M6x20	3

TRANSMISSION

No.	Part number	Description	Qty
79	DUPKC90-02-12	delta bearing seat	2
80	DUPGB/T276-1997;6002	ball bearing 6002	2
81	DUPKC90-02-15	spring	1
82	DUPKC30A-02-23	support for friction disc	1
83	DUPKC30A-02-24	sleeve 13x20x20	1
84	DUPGB/T9074.17-1988;M8x16	bolt M8X16	2
85	DUPGB/T899.1-2000;M12	jam nut M12	1
86	DUPKC21-02C-12	brake spring	1
87	DUPGB/T 109-1986;4×12	rivet 4×12	2
88	DUPKC30A-02-25	brake block	1
89	DUPKC30A-02-26A	bottom plate for transmission box	1
90	DUPKC30A-02-27	position part	1
91	DUPS03*00493	B Pin;Ç 1.5X25	1
92	DUPKC21-02C-17	reset spring	1
93	DUPKC90-02-31	strut	1


TRACK SYSTEM



TRACK SYSTEM

No.	Part number	Description	Qty
1	DUPKC90-03-01A	pedrail bracket,left	1
2	DUPKC90-03-02A	pedrail bracket,right	1
3	DUPKC90-03-03A	front pedrail shaft	1
4	DUPGB/T12-1988	bolt M6x16	14
5	DUPGB/T 889.1-2000	jam nut M6	14
6	DUPKC90-03-04	shaft bushing	4
7	DUPKC90-03-05	big washer	8
8	DUPKC90-03-06	lder pulley	4
9	DUPKC90-03-24	bushing	4
10	DUP6004-2RS	ball bearing 6004-2RS	8
11	DUPGB/T5287-2002	washer 8	4
12	DUPGB/T93-1987	spring washer 8	4
13	DUPGB/T 5780-2000	bolt M8x16	8
14	DUPXL-A	pedrail	2
15	DUPKC90-03-07	clip	2
16	DUPKC90-03-08A	pedrail pulley	2
17	DUPDIN6927	jam nut M8	6
18	DUP6205-2RS	ball bearing 6205-2RS	2
19	DUPKC90-02-11	rhombus bearing seat	2
20	DUPKC90-03-18	left plate for rubber track	1
21	DUPGB/T 5780-2000	bolt M10x45	2
22	DUPKC90-03-10A	pedal assemble	1
23	DUPKC90-03-11A	hook	2
24	DUPKC90-03-25	hook washer	2
25	DUPKC90-03-12	rear axle for pedrail	1
26	DUPGB/T 5780-2000	bolt M10x70	2
27	DUPKC90-03-16	bushing	2
28	DUPKC90-03-13	bushing,middle	2
29	DUPKC90-02-07	plastic bushing	4
30	DUPKC90-03-14	pad	2
31	DUPGB/T 889.1-2000	jam nut M10	6
32	DUPKC90-03-15	reset spring	2
33	DUPGB/T 889.1-2000	nut M8	6
34	DUPGB/T12-1988	bolt M8x18	6
35	DUPKC90-03-19	right plate for rubber track	1
36	DUPKC90-03-20	right scrapper	2
37	DUPKC90-03-21	scraper seat	1
38	DUPKC90-03-23	scraper seat 2	1
39	DUPKC90-03-22	left scrapper	2
40	DUPGB/T 5780-2000	bolt M8x20	2

AUGER




AUGER

No.	Part number	Description	Qty
1	DUPKCA34-01-01A	housing assemble (34)	1
2	DUPKC26-01-06	housing bar (optional)	2
3	DUPKC55-25	plastic nut (optional)	4
4	DUPKC42-01-02	skid shoe	2
5	DUPGB/T96.2-2002	washer 8	6
6	DUPGB/T889.1-2000	nut M8	19
7	DUPKCA34-01-10	skid shoe	2
8	DUPDIN6927	nut M8	9
9	DUPKC34-01-02	shave plate (34)	1
10	DUPGB/T12-1988	bolt M8x16	8
11	DUPGB/T12-1988	bolt M8x18	6
12	DUPKC42-01-05A	bearing seat	2
13	DUPGB/T7810-1995	bearing SB205	2
14	DUPKC42-01-04A	bearing seat 205	2
15	DUPKCA34-01-02A	right auger	1
16	DUPGB/T5782-2000	bolt M6x20	2
17	DUPKCA34-01-25	coupling	2
18	DUPKCA34-01-02A-06	sleeve	4
19	DUPGB/T5782-M8X45	bolt M8x45	2
20	DUPKCA34-01-05	gear box	1
21	DUPGB/T889.1-2000	jam nut M6	6
22	DUPGB/T93-1987	washer 6	4
23	DUPKCA34-01-06A	fan	1
24	DUPKC26-01-18	bolt M6x40	2
25	DUPGB/T5782-2000	bolt M6x30	2
26	DUPKCA34-01-07R	right support	1
27	DUPKCA34-01-07L	left support	1
28	DUPKCA34-01-08A	left auger	1
29	DUPGB/T93-1987	washer 8	2
30	DUPGB/T12-1988	bolt M8x20	2
31	DUPGB/T12-1988	bolt M8x20 (optional)	4
32	DUPGB/T12-1988	bolt M8x25	4
33	DUPGB/T845-1985	screw ST4.2x9.5-F	2
34	DUPKC55-01-21	shovel support	1
35	DUPKC42-01-20	bearing seat	2
36	DUPSB204	ball bearing SB204	1
37	DUPKC42-01-22	belt pulley	1
38	DUPGB/T5287-2002	washer 10	1
39	DUPGB/T5780-2000	bolt M10x25	1

AUGER


No.	Part number	Description	Qty
40	DUPGB/T1095-2003	A flat key 6x20	1
41	DUPKCA34-01-09	washer	2
42	DUPKCA34-01-11	right support for higher plate (optional)	1
43	DUPKCA34-01-12	higher plate (optional)	1
44	DUPKCA34-01-13	left support for higher plate (optional)	1
45	DUPGB /T12-1988	bolt M8x16 (optional)	4
46	DUPGB/T6183.1-2000	nut M8 (optional)	4
47	DUPKCA34-01-14	sleeve	3
48	DUPKCA34-01-15	gear washer	1
49	DUPKCA34-01-16	gear plate	1
50	DUPKCA34-01-17	gear plate cover	1
51	DUPKCA34-01-18	metal cover	1
52	DUPGB/T5780-2000	bolt M8x25	3
53	DUPKCA34-01-19	rubber ring	1
54	DUPKCA34-01-20	output shaft	1

AUGER



No.	Part number	Description	Qty
1	DUPKCA34-01-05-01	Worm case right	1
2	DUPGB/T16674.1-2004	bolt M10x15	1
3	DUPGB/T9877.2-1988	seal ring 25x40x7	2
4	DUPGB/T276-1994	bearing 6205	2
5	DUPKCA34-01-20	auger shaft 34	1
6	DUPGB/T276-1994	bearing 6202	1
7	DUPKCA34-01-05-03	paper washer	1
8	DUPKCA34-01-05-04	worm	1
9	DUPGB/T1095-2003	key A8*25	1
10	DUPKCA34-01-05-05	worm case left	1
11	DUPGB/T9074.17-2002	bolt M6x25	6
12	DUPKCA34-01-05-06	worm shaft	1
13	DUPKCA34-01-05-07	sleeve	1
14	DUPGB/T301-1995	bearing 51104	1
15	DUPGB/T276-1994	bearing 6004	1
16	DUPGB/T9877.2-1988	seal ring 20x35x7	1

CHUTE



CHUTE

No.	Part number	Description	Qty
1	DUPKC42A-03A-1A	chute welded	1
2	DUPKC55-03-17	spring	1
3	DUPGB/T96.2-2002	washer C8	1
4	DUPKC30A-05-2	deflector spring	1
5	DUPKC30A-05-4A	deflector cable	1
6	DUPSGC06*20150128	tie	1
7	DUPKC30A-05-3	strut	1
8	DUPKC42A-03-2A	sealing pad	1
9	DUPKC30A-05-6B	lower hinge	1
10	DUPKC30A-05-7B	hinge axle	1
11	DUPGB/T12618-1990	rivet 4x10	7
12	DUPKC30A-05-08B	upper hinge	1
13	DUPKC42A-03-3	deflector	1
14	DUPKC21-23	washer for barrier	1
15	DUPKC42A-03-4	barrier	1
16	DUPKC55-26	plastic washer	1
17	DUPGB/T91-2000	pin 2*16	1
18	DUPKC42A-03-5	sealing pad	1