


DUCAR

Equipment parts manual

Model : DUESB926T
Snowblower



Picture may not reflect the exact model



No.	Part number	Description	Qty
1	DUPS07*00656	jam nut M8	6
2	DUPKC55-10	right gimbal	1
3	DUPGB/T 6171-2000	nut M8x1	1
4	DUPKC26-04A	gear connector bar	1
5	DUPGB/T 889.1-2000	nut M8	5
6	DUPS07*00447	Concave gasket / 8*22*2	4
7	DUPKC30-05A	Armrest aluminum pad	2
8	DUPGB/T12-1988	bolts M8X55	4
9	DUPGB/T6563-2014	Hexagon head combination bolts M6X16	4
10	DUPKC30A-04A	Belt cover	1
11	DUPKC30A-07	Belt rod	1
12	DUPKC42A-03A	chute assebmly	1
13	DUPKC55-24	Snow shovel	1
14	DUPKC55-15	Helical bracket washers	1
15	DUPKC26-11	Long washers	1
16	DUPKC26-14	Hollow worm	1
17	DUPKC26-12	Mandrel	1
18	DUPKC26-15	Lower connection tube	1
19	DUPGB/T 879-2000	Elastic cylindrical pin 3 * 18	2
20	DUPKC26-16	Rotating frame cover	1
21	DUPGB/T9074.17-1994	screw M6X16	2
22	DUPKC26-10A	Rotating frame	1
23	DUPGB/T12-1988	bolt M8X16	3
24	DUPGB/T889.1-2000	hexagon lock nut M8	3
25	DUPGB/T 96.2-2002	washer C6	2
26	DUPKC26-17	friction pad	1
27	DUPKC26-18	friction spring	1
28	DUP4LXP900	belt	2
29	DUPGB/T9074.17-1994	bolt M8x20	2
30	DUPGB/T 96.2-2002	washer C8	2
31	DUPKC30-17	cable holder	1
32	DUPKC30A-08	belt cover washer	2

This exploded view diagram illustrates the assembly of a vacuum cleaner. The components are numbered 1 through 60, corresponding to the parts list on the right. The diagram shows the main body (1), motor unit (2), and various internal and external components like the motor (3), fan (4), and various fasteners (5-10). It also shows the attachment of the motor housing (11), the main body (12), and the various internal components like the motor (13), fan (14), and various fasteners (15-20). The diagram also shows the attachment of the motor housing (21), the main body (22), and the various internal components like the motor (23), fan (24), and various fasteners (25-30). The diagram also shows the attachment of the motor housing (31), the main body (32), and the various internal components like the motor (33), fan (34), and various fasteners (35-40). The diagram also shows the attachment of the motor housing (41), the main body (42), and the various internal components like the motor (43), fan (44), and various fasteners (45-50). The diagram also shows the attachment of the motor housing (51), the main body (52), and the various internal components like the motor (53), fan (54), and various fasteners (55-60).


HANDLE

No.	Part number	Description	Qty
1	DUPKC30-03C-01R	upper handle (right)	1
2	DUPKC30-03-02	panel	1
3	DUPGB/T899.1-2000	nut M8	10
4	DUPKC30-03-44R	right pulley set	1
5	DUPGB/T12-1988	bolt M8x40	4
6	DUPGB/T5780-2000	bolt M6x20	2
7	DUPKC21-02-2	small shaft sleeve	2
8	DUPKC40-28	pulley	2
9	DUPKCA28-04-03	handle seat	2
10	DUPGB/T12-1988	bolt M8x45	2
11	DUPKC30-03-49	long cable	2
12	DUPGB/T12-1988	bolt M8x35	2
13	DUPS03*00493	B pin ϕ 1.5X25	4
14	DUPKC30-03-09	gear handle lever	1
15	DUPGB/T41-2000	nut M10	2
16	DUPKC30-03-2(M4)	gear handle	2
17	DUPKC30-03-11GGP	deflector handle lever	1
18	DUPGB/T 6183.1-2000	jam nut M6	4
19	DUPKC30-03-45	spring	2
20	DUPKCA28-04-14	short rod	1
21	DUPKCA28-04-04	right control lever	1
22	DUPKC55-03-15	rubber pad	2
23	DUPGB/T5287-2002	washer 8	2
24	DUPGB/T 70.1-1985	screw M8x150	1
25	DUPKCA28-04-17	stopper	1
26	DUPKC30-03-50	pin	2
27	DUPKCA28-04-16	cam	1
28	DUPKC55-03-11	stopper spring	1
29	DUPGB/T 70.1-1985	screw M8x60	1
30	DUPKCA28-04-08	long rod	1
31	DUPGB/T 12618-1990	rivet 4x10	4
32	DUPKC90-04-04A	heated handle	2
33	DUPKCA28-04-10	left control lever	1
34	DUPGB/T899.1-2000	jam nut M6	2
35	DUPKC55-03-05-6	short bushing	2
36	DUPKC30-03-14	input wire	1
37	DUPASW-07D	switch	2
38	DUPKC30A-05-4	deflector cable	1
39	DUPKCD26-06-2	spring	1

HANDLE

No.	Part number	Description	Qty
40	DUPKC30-03-44L	left pulley seat	1
41	DUPGB/T70.1-1985	screw M5x35	2
42	DUPKC30-03-08	differential handle	1
43	DUPGB/T 889.1-2000	jam nut M6	1
44	DUPGB/T95-2002	flast washer 6	1
45	DUPKC30-03-06	handle bolt	1
46	DUPKC30-03-05	differential handle seat	1
47	DUPKC30-02-06B	differential cable	1
48	DUPKC30-03-32	rotating handle	1
49	DUPKC30-03-31	rubber pad	10
50	DUPKC30-03-23	lower fixing seat for rotating lever	1
51	DUPKC30-03C-01L	upper handle (left)	1
52	DUPKC30-03-22B	flexible shaft	2
53	DUPGB/T 818-2000	screw M6x10	2
54	DUPGB/T95-2002	flat washer 6	2
55	DUPKC30-03-24	decoration plate for light	1
56	DUPGB/T9074.17-1988	bolt M6x16	2
57	DUPKC30-03-26	cover	1
58	DUPGB/T 889.1-2000	jam nut M6	2
59	DUPKC21-03-15	LED light	1
60	DUPGB/T846-1985	screw ST3.5x16-F	2

TRANSMISSION



TRANSMISSION

No.	Part number	Description	Qty
1	DUPKC90-02-21A	handlebar	1
2	DUPKC55-02-25A	handle connecting plate	2
3	DUPGB/T9074.17-1988;M10X45	Bolt M10x45	2
4	DUPGB/T5780-2000;M6X16	Bolt M6x16	8
5	DUPKC30A-02-30	strut	2
6	DUPKC30A-02T-01	cover 2	1
7	DUPGB/T5780-2000;M6X20	bolt M6x20	1
8	DUPKCM24-02C-19	pulley seat	1
9	DUPKC21-02-2	small shaft sleeve	1
10	DUPKC21-02C-01	short wire	1
11	DUPKC40-28	pulley	1
12	DUPGB/T899.1-2000;M6	jam nut M6	1
13	DUPKC30A-02-02	connecting plate	1
14	DUPGB/T9074.17-1988;M8X20	bolt M8X20	4
15	DUPGB/T5780-2000;M8X40	bolt M8X40	4
16	DUPS07*00143	washer 24*8*2	4
17	DUPKC30A-02-29	enging plate	1
18	DUPDIN6927	jam nut M8	4
19	DUPLC180FDS	engine	1
20	DUP3LXP870	belt	1
21	DUPKC30A-02-03	drive wheel	1
22	DUPKC21-02-36	washer	4
23	DUPKC90-02-16	drive pulley 2	1
24	DUPGB/T5287-2002;8	washer 8	1
25	DUPGB/T5786-2000; 5/16-24*1 1/4	bolt 5/16-24*1 1/4	1
26	DUPKC30A-02-04A	transmission box assembly	1
27	DUPGB/T9074.17-1988;M6X20	bolt M6x20	2
28	DUPKC30-02-12	shift connector	1
29	DUPKC90-02-07	plastic sleeve	3
30	DUPKC30A-02T-02	cover 3	1
31	DUPKC55-02-05	shift fork	1
32	DUPGB/T9074.17-1988;M6x16	bolt M6X16	13
33	DUPKC30A-02-05	bearing seat	2
34	DUPGB/T276-1997;6200	ball bearing 6200	4
35	DUPGB/T894.1-1986;25	circlip 25	1
36	DUPKC21-02-13	shift bearing	1
37	DUPKC30A-02-06	sleeve 15x20x15	1
38	DUPKC21-02-12B	rubber wheel seat	1
39	DUPKC30A-02-07	small gear	1


TRANSMISSION

No.	Part number	Description	Qty
40	DUPKC21-02-11A	rubber wheel	1
41	DUPKC30A-02-08	sleeve 18x23x18	1
42	DUPKC55-29	B pinchcock	1
43	DUPKC30A-02-9	hexagon shaft	1
44	DUPKC30A-02-10-2	transit shaft	1
45	DUPKC30A-02T-3	chain wheel	1
46	DUPKC30A-02-11	small chain wheel	1
47	DUPKC30A-02-12	sleeve 12x15x8	1
48	DUPGB/T1243-1997;085-26	chain 085-26	1
49	DUPKC30-02-16A	shaft sleeve	2
50	DUPGB/T9074.17-1988;M8X16	bolt M8x16	4
51	DUPKC90-02-11	bearing seat	2
52	DUPGB/T899.1-2000	jam nut M8	4
53	DUPGB/T899.1-2000;M8	ball bearing 6205	2
54	DUPKC30A-02-14	shaft sleeve 25x34x16	1
55	DUPKC30A-02-15	differential	1
56	DUPKC30A-02-16	short semi-shaft	1
57	DUPGB/T1095-2003;6X4X45	flat key 6x4x45	2
58	DUPKC30A-02-17	bronze sleeve 1	1
59	DUPKC30A-02-18	fork plate	1
60	DUPKC30-02-07	auxiliary differential part	1
61	DUPKC30-02-05	big spring	1
62	DUPKC30-02-06B	differential cable	1
63	DUPKC30A-02-19	bronze sleeve 2	1
64	DUPKC30A-02-20	long shaft	1
65	DUPKC30A-02-31	tension connector	1
66	DUPGB/T848-2002;ç12	flat washer;ç12	1
67	DUPGB/T955-1987;ç13	spring washer ç13	1
68	DUPKC21-02C-09	fixing block	1
69	DUPGB/T5780-2000;M8x30	bolt M8X30	1
70	DUPKC55-02-21A	small tension pulley	1
71	DUPKC21-02C-10	small tension plate	1
72	DUPGB/T12-1988;M8X45	bolt M8x45	1
73	DUPKC30A-02A-5	big tension combination	1
74	DUPKC55-01-24	bushing	1
75	DUPKC55-01-27	big tension pulley	1
76	DUPKC55-01-26	pad	1
77	DUPKC21-02C-13	belt pulley	1
78	DUPGB/T9074.17-1988;M6x20	bolt M6x20	3

TRANSMISSION

No.	Part number	Description	Qty
79	DUPKC90-02-12	delta bearing seat	2
80	DUPGB/T276-1997;6002	ball bearing 6002	2
81	DUPKC90-02-15	spring	1
82	DUPKC30A-02-23	support for friction disc	1
83	DUPKC30A-02-24	sleeve 13x20x20	1
84	DUPGB/T9074.17-1988;M8x16	bolt M8X16	2
85	DUPGB/T899.1-2000;M12	jam nut M12	1
86	DUPKC21-02C-12	brake spring	1
87	DUPGB/T 109-1986;4×12	rivet 4×12	2
88	DUPKC30A-02-25	brake block	1
89	DUPKC30A-02-26A	bottom plate for transmission box	1
90	DUPKC30A-02-27	position part	1
91	DUPS03*00493	B Pin;Ç 1.5X25	1
92	DUPKC21-02C-17	reset spring	1
93	DUPKC90-02-31	strut	1


TRACK SYSTEM



TRACK SYSTEM

No.	Part number	Description	Qty
1	DUPKC90-03-01A	pedrail bracket,left	1
2	DUPKC90-03-02A	pedrail bracket,right	1
3	DUPKC90-03-03A	front pedrail shaft	1
4	DUPGB/T12-1988	bolt M6x16	14
5	DUPGB/T 889.1-2000	jam nut M6	14
6	DUPKC90-03-04	shaft bushing	4
7	DUPKC90-03-05	big washer	8
8	DUPKC90-03-06	lder pulley	4
9	DUPKC90-03-24	bushing	4
10	DUP6004-2RS	ball bearing 6004-2RS	8
11	DUPGB/T5287-2002	washer 8	4
12	DUPGB/T93-1987	spring washer 8	4
13	DUPGB/T 5780-2000	bolt M8x16	8
14	DUPXL-A	pedrail	2
15	DUPKC90-03-07	clip	2
16	DUPKC90-03-08A	pedrail pulley	2
17	DUPDIN6927	jam nut M8	6
18	DUP6205-2RS	ball bearing 6205-2RS	2
19	DUPKC90-02-11	rhombus bearing seat	2
20	DUPKC90-03-18	left plate for rubber track	1
21	DUPGB/T 5780-2000	bolt M10x45	2
22	DUPKC90-03-10A	pedal assemble	1
23	DUPKC90-03-11A	hook	2
24	DUPKC90-03-25	hook washer	2
25	DUPKC90-03-12	rear axle for pedrail	1
26	DUPGB/T 5780-2000	bolt M10x70	2
27	DUPKC90-03-16	bushing	2
28	DUPKC90-03-13	bushing,middle	2
29	DUPKC90-02-07	plastic bushing	4
30	DUPKC90-03-14	pad	2
31	DUPGB/T 889.1-2000	jam nut M10	6
32	DUPKC90-03-15	reset spring	2
33	DUPGB/T 889.1-2000	nut M8	6
34	DUPGB/T12-1988	bolt M8x18	6
35	DUPKC90-03-19	right plate for rubber track	1
36	DUPKC90-03-20	right scrapper	2
37	DUPKC90-03-21	scraper seat	1
38	DUPKC90-03-23	scraper seat 2	1
39	DUPKC90-03-22	left scrapper	2
40	DUPGB/T 5780-2000	bolt M8x20	2

AUGER




AUGER

No.	Part number	Description	Qty
1	DUPKCA26-01-01A	housing assemble (26)	1
2	DUPKC26-01-06	housing bar (optional)	2
3	DUPKC55-25	plastic nut (optional)	4
4	DUPKC42-01-02	skid shoe	2
5	DUPGB/T96.2-2002	washer 8	6
6	DUPGB/T889.1-2000	nut M8	18
7	DUPKCA34-01-10	skid shoe	2
8	DUPGB/T6183.1-2000	nut M8	16
9	DUPGB/T12-1988	bolt M8x16	7
10	DUPKC26-01-03	shave plate (26)	1
11	DUPDIN6927	nut M8	9
12	DUPKC42-01-05A	bearing seat	2
13	DUPGB/T7810-1995	bearing SB205	2
14	DUPKC42-01-04A	bearing seat 205	2
15	DUPGB/T12-1988	bolt M8x18	6
16	DUPKCA26-01-02	right auger	1
17	DUPKCA34-01-25	coupling	2
18	DUPKCA34-01-02A-06	sleeve	4
19	DUPGB/T5782-M8X45	bolt M8x45	2
20	DUPKCA34-01-05	gear box	1
21	DUPGB/T889.1-2000	jam nut M6	6
22	DUPGB/T93-1987	washer 6	4
23	DUPKCA34-01-06A	fan	1
24	DUPGB/T5782-2000	bolt M6x40	2
25	DUPGB/T5782-2000	bolt M6x30	2
26	DUPKCA34-01-07R	right support	1
27	DUPKCA34-01-07L	left support	1
28	DUPKCA26-01-03	left auger	1
29	DUPGB/T93-1987	washer 8	2
30	DUPGB/T12-1988	bolt M8x20	2
31	DUPGB/T12-1988	bolt M8x20 (optional)	4
32	DUPGB/T12-1988	bolt M8x25	4
33	DUPGB/T845-1985	screw ST4.2x9.5-F	2
34	DUPKC55-01-21	shovel support	1
35	DUPKC42-01-20	bearing seat	2
36	DUPSB204	ball bearing SB204	1
37	DUPKC42-01-22	belt pulley	1
38	DUPGB/T5287-2002	washer 10	1
39	DUPGB/T5780-2000	bolt M10x25	1

AUGER


No.	Part number	Description	Qty
40	DUPGB/T1095-2003	A flat key 6x20	1
41	DUPKCA34-01-14	sleeve	3
42	DUPKCA34-01-15	gear washer	1
43	DUPKCA34-01-16	gear plate	1
44	DUPKCA34-01-17	gear plate cover	1
45	DUPKCA34-01-18	metal cover	1
46	DUPGB/T5780-2000	bolt M8x25	3
47	DUPKCA34-01-19	rubber ring	1
48	DUPKCA34-01-09	washer	2
49	DUPKCA34-01-11	right support for higher plate (optional)	1
50	DUPKCA26-01-04	higher plate (optional)	1
51	DUPKCA34-01-13	left support for higher plate (optional)	1
52	DUPGB/T12-1988	bolt M8x16 (optional)	4
53	DUPGB/T6183.1-2000	nut M8 (optional)	4
54	DUPKCA26-01-05	output shaft	1

AUGER



No.	Part number	Description	Qty
1	DUPKCA34-01-05-01	Worm case right	1
2	DUPGB/T16674.1-2004	bolt M10x15	1
3	DUPGB/T9877.2-1988	seal ring 25x40x7	2
4	DUPGB/T276-1994	bearing 6205	2
5	DUPKCA26-01-05	auger shaft 26	1
6	DUPGB/T276-1994	bearing 6202	1
7	DUPKCA34-01-05-03	paper washer	1
8	DUPKCA34-01-05-04	worm	1
9	DUPGB/T1095-2003	key A8*25	1
10	DUPKCA34-01-05-05	worm case left	1
11	DUPGB/T9074.17-2002	bolt M6x25	6
12	DUPKCA34-01-05-06	worm shaft	1
13	DUPKCA34-01-05-07	sleeve	1
14	DUPGB/T301-1995	bearing 51104	1
15	DUPGB/T276-1994	bearing 6004	1
16	DUPGB/T9877.2-1988	seal ring 20x35x7	1

CHUTE



CHUTE

No.	Part number	Description	Qty
1	DUPKC42A-03A-1A	chute welded	1
2	DUPKC55-03-17	spring	1
3	DUPGB/T96.2-2002	washer C8	1
4	DUPKC30A-05-2	deflector spring	1
5	DUPKC30A-05-4A	deflector cable	1
6	DUPSGC06*20150128	tie	1
7	DUPKC30A-05-3	strut	1
8	DUPKC42A-03-2A	sealing pad	1
9	DUPKC30A-05-6B	lower hinge	1
10	DUPKC30A-05-7B	hinge axle	1
11	DUPGB/T12618-1990	rivet 4x10	7
12	DUPKC30A-05-08B	upper hinge	1
13	DUPKC42A-03-3	deflector	1
14	DUPKC21-23	washer for barrier	1
15	DUPKC42A-03-4	barrier	1
16	DUPKC55-26	plastic washer	1
17	DUPGB/T91-2000	pin 2*16	1
18	DUPKC42A-03-5	sealing pad	1