

DUCAR


Engine parts manual

Model : DUESB1334
34" snowblower




Picture may not reflect the exact model

CYLINDER HEAD




No.	Part number	Description	Qty
1	DUP380140441-0001	BOLT , FLANGE , M6×14	4
2	DUP120220023-0001	COVER COMP ., HEAD	1
3	DUP380740671-0001	TUBE,BREATHER	1
4	DUP120250021-0001	PACKING , HEAD COVER	1
5	DUP380140337-0001	BOLT , FLANGE , M10×80	4
6	DUP270960014-0001	PLUG , SPARK	1
7	DUP 380180099-0001	BOLT , STUD , IN.M8×54	2
8	DUP180650085-0001	GASKET , EX.PIPE	1
9	DUP120080404-0001	HEAD COMP .,CYLINDER	1
10	DUP120150142-0001	GASKET , CYLINDER	1
11	DUP380600116-0001	PIN , DOWEL12×20	2
12	DUP380140001-0006	BOLT , FLANGE , M6×12	1
13	DUP160190006-0001	SHROUD	1
14	DUP380180092-0001	BOLT, STUD, INTAKE	2

CRANKCASE




No.	Part number	Description	Qty
1	DUP110810111-0001	CRANK CASE	1
2	DUP380630099-0001	BEARING , RADIAL BALL	2
3	DUP130450016-0001	WEIGHT,BALANCER	1
4	DUP171630003-0001	SHAFT , GOVERNOR ARM	1
5	DUP380650339-0001	OIL SEAL	1
6	DUP380450522-0001	WASHER	1
7	DUP381350004-0001	PIN, LOCK	1
8	DUP380450516-0001	WASHER 12×20×2	1
9	DUP110260024-0001	BOLT, DRAIN PLUG	1
10	DUP380650494-0001	OIL SEAL 35×52×7	1
11	DUP270280017-0001	PLATE,WINDING	1
12	DUP380140011-0004	BOLT , FLANGE , M6×10	1
13	DUP380140001-0006	BOLT , FLANGE , M6×12	1
14	DUP380940346-0001	CABLE CLEAT	1
15	DUP380930023-0001	CLIP,WIRE HARNESS	1
16	DUP270210007-0001	COIL ASSY .	1
17	DUP380140054-0003	BOLT , FLANGE , M6×30	2
18	DUP110940005-0001	BLEED-OFF PIPE	1

CRANKCASE COVER




No.	Part number	Description	Qty
1	DUP110820053-0001	CRANK CASE COVER	1
2	DUP171750004-0001	GOVERNOR KIT	1
3	DUP110690097-0003	CAP ASSY.	1
4	DUP110830023-0001	GASKET, CASE COVER	1
5	DUP380600119-0001	DOWEL PIN 8×12	2
6	DUP380630141-0002	BEARING	1
7	DUP380650495-0001	OIL SEAL 35×52×7	1
8	DUP110690046-0001	CAP ASSY.	1
9	DUP380140003-0007	BOLT , FLANGE , M6×20	1
10	DUP380140005-0006	BOLT , FLANGE M8×40	8
11	DUP110260025-0001	BOLT,DRAIN PLUG	1

CRANKSHAFT/PISTON




No.	Part number	Description	Qty
1	DUP130070114-0001	RING SET	1
2	DUP130030127-0001	PISTON	1
3	DUP130060034-0001	PIN,PISTON	1
4	DUP380560057-0001	CLIP,PISTON PIN	2
5	DUP130150049-0001	ROD ASSY ., CONNECTING	1
6	DUP130290267-0001	CRANKSHAFT COMP A5	1
7	DUP380620052-0001	KEY	1




No.	Part number	Description	Qty
1	DUP140450023-0001	ARM COMP.	1
2	DUP140710002-0001	PLATE , PUSH ROD GUIDE	1
3	DUP140670006-0001	PUSH ROD	2
4	DUP140690004-0001	LIFTER , VALVE	2
5	DUP140020110-0001	CAMSHAFT ASSY	1
6	DUP140320002-0001	ROTATOR,VALVE	2
7	DUP140390015-0001	LOCER, VALVE	4
8	DUP140380021-0001	RETAINER,EX.VALVE SPRING	2
9	DUP140340025-0001	SPRING,VALVE	2
10	DUP140360010-0001	SEAT,VALVE SPRING	1
11	DUP140400012-0001	SEAL,VALVE STEM	1
12	DUP500550032-0001	VALVE COMP.	1

STARTER SUBASSEMBLY




No.	Part number	Description	Qty
1	DUP193490164-0001	RECOIL STARTER COMP.	1
2	DUP160210051-0001	COVER COMP ., FAN	1
3	DUP193500081-0001	STARTER ASSY.	1
4	DUP380140531-0001	BOLT , FLANGE , M6×8	4
5	DUP380140001-0005	BOLT , FLANGE , M6×12	5
6	DUP380930024-0001	CLIP,WIRE HARNESS	1

DIVERSION ASSEMBLY




No.	Part number	Description	Qty
1	DUP160190042-0001	SHROUD	1
2	DUP380140001-0006	BOLT , FLANGE , M6×12	1

FLYWHEEL/COIL ASSEMBLY




No.	Part number	Description	Qty
1	DUP270920254-0001	COIL ASSY ., IGNITION	1
2	DUP380140095-0005	BOLT , FLANGE , M6×25	2
3	DUP270020153-0001	FLYWHEEL COMP	1
4	DUP160180021-0001	FAN COOLING	1
5	DUP193590007-0001	PULLEY,STARTER	1
6	DUP380370050-0001	NUT SPECIAL M16	1
7	DUP271660054-0001	OIL FILLER ASSY	1
8	DUP273210001-0003	SWITCH KEY	1

CARBURETOR




No.	Part number	Description	Qty
1	DUP380750404-0001	HOSE,CARBURETOR	1
2	DUP380960121-0005	CLIP , TUBE	2
3	DUP170430062-0001	PACKING , INSULATOR	1
4	DUP170440041-0001	INSULATOR,CARBURETOR	1
5	DUP170430050-0001	PACKING,CARBURETOR	1
6	DUP170021345-0001	CARBURETOR ASSY	1
7	DUP173390001-0001	AIR PUMP PCOMP,CARBURETOR	1
8	DUP271460071-0001	LEVER,CHOKE	1
9	DUP170430076-0001	SPACER COMP ., AIR CLEANER	1

STARTER MOTOR




No.	Part number	Description	Qty
1	DUP270350073-0002	Starter motor assembly	1
2	DUP380140051-0005	BOLT , FLANGE	2
3	DUP270810095-0001	CONTACTOR ASSY	1
4	DUP380140053-0002	BOLT , FLANGE	2
5	DUP270370012-0001	CABLE ASSY.,STARTING	1
6	DUP271050044-0001	BOX,ELECTRIC STARTING CONTROL	1

CONTROL SYSTEM




No.	Part number	Description	Qty
1	DUP171590005-0001	ROD, GOVERNOR	1
2	DUP171610001-0001	SPRING, THROTTLE RETURN	1
3	DUP171600035-0001	SPRING, GOVERNOR	1
4	DUP173710004-0001	GUM COVER,CONTROL HANDLE	1
5	DUP380200011-0006	SCREW ,M5×30	1
6	DUP380140011-0004	BOLT , FLANGE , M6×10	2
7	DUP380370048-0001	NUT, FLANGE,6MM	1
8	DUP171680061-0001	CONTROL ASSY.	1
9	DUP380370048-0001	NUT, FLANGE,6MM	1
10	DUP171620021-0003	ARM, GOVERNOR	1
11	DUP380250002-0001	BOLT, QUADRATE HEAD6×21	1
12	DUP171620020-T251	ARM, GOVERNOR	1
13	DUP380250002-0001	BOLT, QUADRATE HEAD6×21	1

AIR FILTER




No.	Part number	Description	Qty
1	DUP380370048-0003	NUT, FLANGE,6MM	2
2	DUP180020682-0001	AIR CLEANER ASSY	1

MUFFLER




No.	Part number	Description	Qty
1	DUP180571637-0001	MUFFLER ASSY.	1
2	DUP380340005-0005	NUT	2
3	DUP380140215-0004	BOLT , FLANGE , M6×14	4
4	DUP380140070-0006	BOLT , FLANGE	2
5	DUP180960121-0001	Protector, MUFFLER COMP.	1

FUEL TANK



No.	Part number	Description	Qty
1	DUP170720009-0001	FILTER , FUEL	1
2	DUP380200071-0002	SCREW ,M4×18	1
3	DUP172840013-0001	HOLDER,FUEL TANK (Right)	1
4	DUP170500726-0003	TANK COMP ., FUEL	1
5	DUP172840012-0001	HOLDER,FUEL TANK(Left)	1
6	DUP170660077-0001	JOINT ASSY. , FUEL TANK	1
7	DUP170870074-0001	CAP COOMP,FUEL FILLER	1
8	DUP380140004-0004	BOLT , FLANGE , M8×20	4
9	DUP380140215-0004	BOLT , FLANGE , M6×14	4
10	DUP380960121-0001	CLIP , TUBE	2
11	DUP380750405-0001	TUBE , FUEL	1
12	DUP380370048-0001	NUT, FLANGE,M6	1
13	DUP380960121-0001	CLIP , TUBE	2
14	DUP170980081-0001	FUEL SWITCH	1
15	DUP173260001-0002	KNOB FUEL SWITCH	1

COVER



No.	Part number	Description	Qty
1	DUP380140215-0004	BOLT , FLANGE , M6×14	3
2	DUP661280005-0001	COVER, ENGINE	1
3	DUP380140215-0004	BOLT , FLANGE , M6×14	1
4	DUP 380140002-0007	BOLT , FLANGE , M6×16	1
5	DUP380370048-0003	NUT, FLANGE,6MM	2
6	DUP343210011-0001	REAR SOVER TANK	1
7	DUP380140004-0004	BOLT , FLANGE , M8×20	1
8	DUP 380140002-0007	BOLT , FLANGE , M6×16	1
9	DUP661280006-0001	COVER, ENGINE	1
10	DUP380930023-0001	CLIP,WIRE HARNESS	1