


DUCAR

Equipment parts manual

Model : DUEDLG7500IR
7500W Inverter generator



Picture may not reflect the exact model



No.	Part number	Description	Qty
1	DUP111003000915	ENGINE ASSY DH300B	1
2	DUP94552	FIBERGLASS TUBE	1
3	DUP506868	TRI-FUEL SWITCH PRESS BLOCK	1
4	DUP500018	RECOIL HANDLE	1
5	DUP500017	RECOIL HANDLE COVER	1
6	DUP503026	ISOLATION PAD	2
7	DUP500942	FUNNEL	1
8	DUP506985	SELECTOR SWITCH	1
9	DUP91336	BOLT M6×35	4
10	DUP507208	PROTECTIVE COVER	4
11	DUP94091	FLAT WASHER	2
12	DUP92078	SCREW M6X16	41
13	DUP545331	PRESSURE REDUCING VALVE	1
14	DUP95838	LOW PRESSURE HOSE	1
15	DUP506828	SHORT WIRE	1
16	DUP94003	TOOTH WASHER 6	3
17	DUP506391	TRI-FUEL SWITCH MOUNT	1
18	DUP506814	FUEL TANK	1
19	DUP245406-126	ONE WAY VALVE ASSEMBLY	1
20	DUP503033	PULL ROD SEAT	1
21	DUP94402	FUEL LINE CLAMP	2
22	DUP94408	FUEL LINE CLAMP	3
23	DUP500019-116	PULL ROPE GUIDE PLATE	1
24	DUP504072	FILTER	1
25	DUP506819	BATTERY HOLDER	1
26	DUP503028	FUEL CAP	1
27	DUP503671	FUEL TANK FILTER	1
28	DUP504071	RUBBER SLEEVE	1
29	DUP506662	LIFTER	1
30	DUP506663	LIFTER	1
31	DUP506809	LIFTER	1
32	DUP50280080	SECONDARY PRESSURE REDUCING VALVE	1
33	DUP506810	LIFTER	1
34	DUP506666	THE BEAM	1
35	DUP506813	THE BEAM	1
36	DUP503077	FILTER	1
37	DUP95168	BREATHING HOSE	1
38	DUP97710	FUEL LINE	1
39	DUP97704	FUEL LINE	1
40	DUP506805	PANEL REAR COVER	1
41	DUP506806	BOTTOM PLATE	1
42	DUP506816-116	KNOB	1
43	DUP92012	SCREW M5*18	4
44	DUP506675	THE BEAM	1
45	DUP506817	BAFFLE	1

No.	Part number	Description	Qty
46	DUP506802-175A	LEFT PANEL	1
47	DUP506769	CONTROL MODULE ASSEMBLY	1
48	DUP553129	INVERTER MODULE	1
49	DUP506683	BRACKET	1
50	DUP506815-052	DECORATIVE BOARD	1
51	DUP506803-175A	RIGHT PANEL	1
52	DUP506804-126	TOP COVER	1
53	DUP94411	FUEL HOSE CLIP	2
54	DUP94418	RUBBER SLEEVE	1
55	DUP506808	PLUG	5
56	DUP506658-116	WHEEL COVER	2
57	DUP506659	WHEEL	2
58	DUP553251	PANEL ASSEMBLY	1
58.1	DUP6387	CHARGING SOCKET	1
58.2	DUP6502/6408	SWITCH	1
58.3	DUP9032	ECO SWITCH	1
58.4	DUP9369/9456	USB	1
58.5	DUP6257	EC08 CHARGING MODULE	1
58.6	DUP536003	ONE PUSH BOTTON SWITCH	1
58.7	DUP9021	VOLTAGE RESET SWITCH	1
58.8	DUP6032/6676	SOCKET	1
58.9	DUP6441-20/6404	THERMAL PROTECTOR	1
58.10	DUP6441-30/6404	THERMAL PROTECTOR	1
58.11	DUP9358	MULTIFUNCTION TABLE	1
58.12	DUP6015/6679	TT-30R RECEPACIE	1
58.13	DUP6525-30/6404	BIPOLAR CIRCUIT BREAKER	1
58.14	DUP6434-25/6406	BREAKER	1
58.15	DUP9193	PARALLEL SOCKET	1
58.16	DUP6241/6678	AMERICAN 4 HOLE INDUSTRIAL SOCKET	1
58.17	DUP9132	GROUNDING BOLT	1
59	DUP506818	FUEL SLOT	1
60	DUP506807	PLUG	1
61	DUP506673	ISOLATION SUPPORT	4
62	DUP599302	ANCHOR EAR	3
63	DUP91460	BOLT M6*25	4
64	DUP503782	FUEL NOZZLE	1
65	DUP92328	BOLT M4*12	2
66	DUP506800-126	LEFT FRAME	1
67	DUP99506	SCREWDRIVER	1
68	DUP506674-506	HANDLE	2
69	DUP506811	BRACKET	1
70	DUP500060	LOCK CLIP	37
71	DUP500661	BLIND RIVET	2
72	DUP99033	SPARK PLUG SLEEVE	1
73	DUP94166	AXIS CHECKING RING	2

No.	Part number	Description	Qty
74	DUP506680	BRACKET	1
75	DUP553254	DEPUTY WIRING HARNESS	1
76	DUP599099-126	COVER	1
77	DUP553097	SHORT WIRE	1
78	DUP504237	CLIP	10
79	DUP503035	PULL ROD ASSEMBLY	1
80	DUP511007	BATTERY	1
81	DUP90026	NUT M8	2
82	DUP90019	NUT M8	16
83	DUP91327	BOLT M6*12	24
84	DUP506254	BATTERY WIRING ASSEMBLY	1
85	DUP506927	MICROSWITCH	1
86	DUP506682	SEALING RING	1
87	DUP91306	BOLT M6*25	2
88	DUP91825	SCREW M5*12	12
89	DUP92005	SCREW M4*12	3
90	DUP92032	SCREW M4*16	1
91	DUP94217	FLAT WASHER	2
92	DUP99519	BEARING CLIP	8
93	DUP506801-126	RIGHT FRAME	1
94	DUP99585	FIXED WRENCH	1
95	DUP99754	OIL BOTTLE ASSEMBLY	1