


DUCAR

Engine parts manual

Model : DUEDG9250E-HD Generator



Picture may not reflect the exact model



No.	Part number	Description	Qty
1	DUP260223	CRANKCASE	1
2	DUP93002	BALL BEARING	2
3	DUP93512	OIL SEAL	2
4	DUP93514	SEAL,GOVERNOR ARM SHAFT	1
5	DUP263901	SHAFT,GOVERNOR ARM	1
6	DUP96806	WASHER,GOVERNOR ARM SHAFT	1
7	DUP263902	PIN,LOCK	1
8	DUP91817	BOLT, DRAIN PLUG	1
9	DUP94004	WASHER,DRAIN PLUG	1
10	DUP265102	SWITCH ASSEMBLY,OIL LEVEL	1
11	DUP91329	BOLT M6X16	2
12	DUP240904	DOWEL PIN,CASECOVER	2
13	DUP261205	PISTON	1
14	DUP261604	SCRAPER RING SET ,PISTON	1
15	DUP261503	ROD ASSEMBLY, CONNECTING	1
16	DUP265501	PIN, PISTON	1
17	DUP261301	CLIP, PISTON	2
18	DUP260111	COVER ASSEMBLY, CRANKCASE	1
19	DUP93015	BALL BEARING	1
20	DUP264301	GOVERNOR ASSEMBLY	1
21	DUP271002	CYLINDER HEAD	1
22	DUP271702	VALVE,IN	1
23	DUP275902	VALVE EXHAUST	1
24	DUP261807	RETURNER,INTAKE VALVE	2
25	DUP93513	OIL SEAL,VALVE	2
26	DUP266002	SPRING,VALVE	2
27	DUP260802	LOCKINMG FLAPS	4
28	DUP261805	SEAT, VALVE SPRING,EX	2
29	DUP262201	PLATE,PUSH ROD GUIDE	1
30	DUP262101	ROCKER ASSY	2
31	DUP261806	ROTATOR	2
32	DUP91016	BOLT, STUD	2
33	DUP91007	BOLT, STUD	2
34	DUP96083	PACKING,EXHAUST	1
35	DUP95205	EXHAUST PIPE	1
36	DUP94206	SPRING WASHER	2
37	DUP90011	NUT M8	2
38	DUP262814	CARBURETOR ASSEMBLY	1
39	DUP96967	FUEL LINE	1
40	DUP94403	CLIP,FUEL LINE	1
41	DUP264002	GOVERNOR ARM	1
42	DUP599601	CLIP,WIRE HARNESS	1
43	DUP90016	NUT M6	2
44	DUP260360	CRANKSHAFT ASSEMBLY	1
45	DUP266101	LIFTER,VALVE	2

No.	Part number	Description	Qty
46	DUP96072	PACKING,CASECOVER	1
47	DUP260301	BALANCING SHAFT	1
48	DUP262012	CAMSHAFT ASSEMBLY	1
49	DUP91348	BOLT M8X35	2
50	DUP91349	BOLT M8X40	7
51	DUP260901	PIN, DOWEL	2
52	DUP96089	GASKET,CYLINDER HEAD	1
53	DUP92353	BOLT M10×1.25×87	4
54	DUP97108	SPARK PULG	1
55	DUP261901	ROD,PUSH	2
56	DUP270501	SHROUD	1
57	DUP91325	BOLT M6X12	9
58	DUP261101	COVER COMP,CYLINDER HEAD	1
59	DUP96075	PACKING,HEADCOVER	1
60	DUP91819	LOCK BOLT	1
61	DUP264404	SHROUD ASSY,UPPER	1
62	DUP260402	FLYWHEEL ASSEMBLY	1
63	DUP264601	FAN,RECOIL STARTER	1
64	DUP264501	PULLEY,STARTER	1
65	DUP90004	NUT	1
66	DUP97518	IGNITION COIL ASSY	1
67	DUP91331	BOLT M6X25	2
68	DUP96078	PACKING,INTAKE	1
69	DUP262301	INSULATOR,CARBURETOR	1
70	DUP96081	PACKING,CARBURETOR	1
71	DUP262701	ROD,GOVERNOR	1
72	DUP264201	SPRING,THROTTLE RETURN	1
73	DUP264702-175	RECOIL STARTER ASSEMBLY	1
74	DUP260801	CLIP	2
75	DUP262908	AIR CLEANER ASSEMBLY	1
75,1	DUP5205	AIR FILTER	1
76	DUP95606	TUBE,BREATHER	1
77	DUP94401	RUBBER ,FUEL	1
78	DUP264101	SPRING,GOVERNOR	1
79	DUP245104	AMPLIFIER	1
80	DUP265604-295	DIPSTICK	1
81	DUP269901	RUBBER, STARTER ASSY	1
82	DUP97210	CHARGE COIL	1
83	DUP91333	BOLT M6X28	2
84	DUP249901	CLAMPER CORD A	1
85	DUP91340	BOLT M6X8	1
86	DUP269902	CLAMPER CORD A	1
87	DUP97406	STARTING MOTOR ASSEMBLY	1
88	DUP91818	ROCKER ARM FASTENING BOLT ASSEMBLY	2
89	DUP94227	SPACER,CARBURETOR	1
90	DUP95901	BREATHE,TUBE	1