



# DUCAR

## Engine parts manual

Model : DUEDLG4000ISE  
Inverter generator



Picture may not reflect the exact model



<b>No.</b>	<b>Part number</b>	<b>Description</b>	<b>Qty</b>
1	DUP91347	BOLT M8X30	6
2	DUP93507	CRANKCASE OIL SEAL	2
3	DUP245601-313	DIPSTICK ASSEMBLY	1
4	DUP330101	CRANKCASE COVER	1
5	DUP96293	CRANKCASE SEAL WASHER	1
6	DUP240904	CRANKCASE LOCATING PIN	4
7	DUP93010	AXLE BEARING	2
8	DUP240364	CRANKSHAFT ASSEMBLY	1
9	DUP332003	CAMSHAFT ASSEMBLY	1
10	DUP246103	VALVE LIFTER	2
11	DUP241901	PUSH ROD	2
12	DUP91329	BOLT M6X16	2
13	DUP245113	OIL SENSOR ASSEMBLY	1
14	DUP330208	CRANKCASE	1
15	DUP94007	OIL DRAIN BOLT WASHER	2
16	DUP91816	OIL DRAIN BOLT	1
17	DUP97431	STARTING MOTOR ASSEMBLY	1
18	DUP92217	SCREW M4*8	4
19	DUP331500	CONNECTING ROD ASSEMBLY	1
20	DUP245503	PISTON PIN	1
21	DUP241211	PISTON	1
22	DUP241301	PISTON PIN RING	2
23	DUP241607	PISTON RING ASSEMBLY	1
24	DUP331001	CYLINDER HEAD	1
25	DUP96182	AIR INTAKE GASKET	1
26	DUP91029	AIR INLET STUD STUD BOLT	2
27	DUP96051	CARBURETOR GASKET	1
28	DUP96058	CYLINDER HEAD GASKET	1
29	DUP240905	CYLINDER HEAD LOCATING PIN	2
30	DUP91007	AIR EXHAUST STUD STUD BOLT	2
31	DUP96055	EXHAUST SEAL WASHER	1
32	DUP91333	BOLT M6*28	1
33	DUP249919	PLUG	1
34	DUP339915	POLYURETHANE SCREEN	3
35	DUP91359	BOLT M8X60	4
36	DUP97109	SPARK PULG	1
37	DUP241704	INTAKE VALVE	1
38	DUP245904	EXHAUST VALVE	1
39	DUP241806	AIR INLET SPRING LOWER SEAT	1
40	DUP246001	VALVE SPRING	2
41	DUP241801	INTAKE VALVE SPRING SEAT	1
42	DUP241802	AIR INLET SPRING SEAT	1
43	DUP241804	TOP CAP	1
44	DUP242202	VALVE RETAINER ASSEMBLY	1
45	DUP91818	ROCKING ARM TIGHTENING BOLT	2

<b>No.</b>	<b>Part number</b>	<b>Description</b>	<b>Qty</b>
46	DUP242101	ROCKING ARM	2
47	DUP96200	HEADCOVER SEAL WASHER	1
48	DUP241115	CYLINDER HEAD COVER	1
49	DUP241116	INNER COVER OF CYLINDER HEAD COVER	1
50	DUP91325	BOLT M6X12	26
51	DUP330501	STARTER ASSEMBLY	1
52	DUP91864	BOLT	1
53	DUP334501	STARTER PULLY	1
54	DUP90003	NUT M14	1
55	DUP334601	IMPELLER	1
56	DUP500191	ROTOR	1
57	DUP91316	BOLT M6X55	3
58	DUP503726	STATOR	1
59	DUP337001	RESONANT CAVITY ASSEMBLY	1
60	DUP95602	BLAST PIPE	1
61	DUP90016	NUT M6	2
62	DUP94229	SPACER,CARBURETOR	2
63	DUP332825	CARBURETOR ASSEMBLY	1
64	DUP249915	STEP MOTOR SEAT	1
65	DUP91419	BOLT M8*1*25	1
66	DUP249949	STEPPER MOTOR	1
67	DUP599302	LOW PRESSURE HOSE HOOP	1
68	DUP517906	LOW PRESSURE HOSE	1
69	DUP249916	SHIELDING	1
70	DUP332301	CARBURETOR CONNECTION BLOCK	1
71	DUP332901	AIR CLEANER ASSEMBLY	1
72	DUP95918	CONNECTING PIPE	1
73	DUP91330	BOLT M6X20	9
74	DUP249917	BRACKET	1
75	DUP240511	SHIELD	1
76	DUP503697	TRIGGER	1
77	DUP330503	WIND-LEAD-COVER	1
78	DUP94407	CLIP,FUEL LINE	1
79	DUP503785	IGNITION	1
80	DUP330502	UPPER WIND-LEAD-COVER	1
81	DUP91334	BOLT M6X30	2
82	DUP244306	CENTRIFUGAL FAN HOUSING.	1
83	DUP244304	CENTRIFUGAL HOOD PLUG	2
84	DUP91345	BOLT M8*20	4
85	DUP244606	IMPELLER	1
86	DUP334302	CENTRIFUGAL FAN COVER	1
87	DUP243740	MUFFLER ASSEMBLY	1
88	DUP94216	SPARK ARRESTER	1
89	DUP94206	SPRING WASHER	2
90	DUP90011	NUT M8	2

<b>No.</b>	<b>Part number</b>	<b>Description</b>	<b>Qty</b>
91	DUP500057	MUFFLER COVER	1
92	DUP249914	WIRE CLIP	1
93	DUP91426	BOLT M5*10	2
94	DUP599601	METAL CLAMP	4
95	DUP91831	OIL DRAIN SOLENOID	1
96	DUP94035	OIL DRAIN BOLT WASHER	1
97	DUP339905	STENT COMPONENTS	1
98	DUP91342	BOLT M8*12	3