

DUCAR

Equipment parts manual

Model : DUEDLG4000ISE
Inverter generator




Picture may not reflect the exact model

No.	Part number	Description	Qty
1	DUP503001	BRACKET	1
2	DUP503002	BRACKET	1
3	DUP503003	BRACKET	1
4	DUP503745	LEFT CONNECTION PLATE	2
5	DUP503004	ISOLATOR	4
6	DUP90044	NUT M8	14
7	DUP91325	BOLT M6X12	41
8	DUP503731-175	LEFT FRAME	1
9	DUP503739	FRONT HANDLE LEFT BRACKET	1
10	DUP503740	FRONT HANDLE RIGHT BRACKET	1
11	DUP503741	REAR HANDLE LEFT BRACKET	1
12	DUP503743-052	HANDLE	2
13	DUP503774	FUEL TANK	1
14	DUP500008	FUEL TANK ISOLATOR B	2
15	DUP503742	REAR HANDLE RIGHT BRACKET	1
16	DUP503744	FUEL TANK CONNECT BRACKET	2
17	DUP503409	INVETER MODULE	1
18	DUP503013	BRACKET	1
19	DUP91322	BOLT M5×12	4
20	DUP504237	CLIP	6
21	DUP503736	CONTROL PANEL REAR COVER	1
22	DUP503017	BRACKET	1
23	DUP503062	FUEL SWITCH	1
24	DUP95788	FUEL PIPE $\phi 12 \times \phi 6 \times \phi 11 \times \phi 5 \times 80 \text{mm}$	1
25	DUP95789	FUEL PIPE $\phi 12 \times \phi 6 \times 47 \text{mm}$	1
26	DUP95771	FUEL PIPE $\phi 11 \times \phi 5 \times 212 \text{mm}$	1
27	DUP503044	CLIP	1
28	DUP503732-175	RIGHT FRAME	1
29	DUP503733-175	OBSERVATION COVER	1
30	DUP503023	AXLE	1
31	DUP511019	BATTERY	1
32	DUP599606	BATTERY BANDGE	1
33	DUP503048	DC VOLTAGE REGULATOR	1
34	DUP503123	KNOB	1
35	DUP500068	HANDLE PANEL PLUG	5
36	DUP500060	CLIP M6	27
37	DUP503025	PLUG	2
38	DUP503026	ISOLATOR	2
39	DUP503738	MUFFLER COVER	1
40	DUP503028	FUEL TANK CAP	1
41	DUP503029	FUEL SLOT	1
42	DUP92014	SCREW ST4.2*13	3
43	DUP503031	WHEEL	2
44	DUP503032	WHEEL COVER	2
45	DUP500108	MUFFLER SEALING GASCKET	1

No.	Part number	Description	Qty
46	DUP503033	PULL ROD SET	1
47	DUP94402	FUEL HOSE CLIP	2
48	DUP503035	PULL ROD	1
49	DUP503036-052	HANDLE DECORATIVE BOARD	1
50	DUP500017	HANDLE COVER	1
51	DUP91825	SCREW & WASHER M5 X 12	6
52	DUP503734-175	TOP COVER	1
53	DUP503730-175	LEFT PANEL	1
54	DUP503737	COVER	1
55	DUP505027	WIRE SLEEVE	1
56	DUP503270	CHOKE LEVEL	1
57	DUP503735	BOTTOM PLATE	1
58	DUP518801	FILTER	1
59	DUP503077	FILTER	1
60	DUP503132	LOWER LID	1
61	DUP500018	HANDLE	1
62	DUP500044	SHORT CIRCUITING WIRE	2
63	DUP92007	SCREW M4*8	4
64	DUP91348	BOLT M8X35	4
65	DUP94022	METAL WASHER	4
66	DUP92019	SCREW M4*16	4
67	DUP92097	SCREW M6X20	8
68	DUP503165	BATTERY CABLE	1
69	DUP503791	DEPUTY WIRING HARNESS	1
70	DUP94003	TOOTH WASHER	4
71	DUP503894	CONTROL PANEL ASSEMBLY	1
72	DUP500011	OIL SWITCH HOLDER	1
73	DUP92032	SCREW M4X16	1
74	DUP91329	BOLT M6X16	12
75	DUP503746	RIGHT CONNECTION PLATE	2
76	DUP91397	BOLT M6X20	4
77	DUP96801	FUEL TANK WASHER	4
78	DUP92078	BOLT M6X16	19
79	DUP500007	FUEL TANK ISOLATOR A	2
80	DUP92079	BOLT M6X16	1
81	DUP503052	BASE OIL CAP	1
82	DUP503053	BLOCK	2
83	DUP500321	WHEEL AXLE CLIP	2
84	DUP91334	BOLT M6X30	4
85	DUP111002250195	ENGINE ASSEMBLY DHLG225	1
86	DUP94411	FUEL HOSE CLIP Φ 11x0.8	2
87	DUP503082	HOSE	1
88	DUP503310	KNOB PLUG	1
89	DUP503131	UPPER COVER	1
90	DUP503782	FUEL OUTLET	1

No.	Part number	Description	Qty
91	DUP94405	FUEL HOSE CLIP Ø11.5	2
92	DUP94403	FUEL HOSE CLIP Ø7.5	2
93	DUP91345	BOLT M8*20	2
94	DUP599601	METAL CLIP	2
95	DUP91331	BOLT M6X25	2
96	DUP90016	NUT M6	1
97	DUP503128	TEE	1
98	DUP500242	CABLE TRAY	1
99	DUP91330	BOLT M6*20	2
100	DUP95921	TUBE,BREATHER	1
101	DUP500012	SPRING	1
102	DUP500003	STEEL BALL	1
103	DUP50280014	PRESSURE REDUCING VALVE	1
104	DUP545332	PRESSURE REDUCING VALVE	1
105	DUP96120	GASKET	1
106	DUP503127	OURLET CONNECTOR	1
107	DUP517907	LOW PRESSURE HOSE	1
108	DUP503126	INTAKE CONNECTOR	1
109	DUP503130	O-RING	2
110	DUP503134	GEAR	1
111	DUP503133	GEAR	1
112	DUP503199	JACKET	1
113	DUP503136	PLUG	1
114	DUP503129	SWITCH AXIS	1
115	DUP503135	GAS CONTROL LINE	1



Bl	Black	Br	Brown	Y/G	Yellow green
R	Red	Br/R	Brown/red	Y	Yellow
Bu	Blue	Gr	Gray	0	Orange
W	White	P	Pink	R/Y	Red/Yellow
Y	Yellow	Bl/W	Black/white	Bu/W	Blue white

DLG4000i SE