


DUCAR

Engine parts manual

Model : DUEDHP212E
Engine



Picture may not reflect the exact model



No.	Part number	Description	Qty
1	DUP100879855	CRANKCASE	1
2	DUP100938923	BEARING	2
3	DUP100938972	CRANKCASE OIL SEAL	2
4	DUP100882487	CENTRIFUGAL GOVERNOR GEAR ASSEMBLY	1
5	DUP100879823	SWINGING ROD	1
6	DUP100939225	SWINGING ROD GASKET	1
7	DUP100882503	RETAINING CLIP	1
8	DUP100938704	OIL DRAIN BOLT	3
9	DUP100939006	OIL DRAIN BOLT WASHER	3
10	DUP100879896	CRANKSHAFT	1
11	DUP100879884	PISTON	1
12	DUP100879885	PISTON RING ASSEMBLY	1
13	DUP100879886	PISTON PIN	1
14	DUP100879887	PISTON PIN RING	2
15	DUP100879891	CONNECTING ROD ASSEMBLY	1
16	DUP100879899	VALVE LIFTER	2
17	DUP100879879	PUSH ROD	2
18	DUP100879900	CAMSHAFT ASSEMBLY	1
19	DUP100861482	CRANKCASE GASKET	1
20	DUP100879870	CRANKCASE COVER	1
21	DUP100882816	CRANKCASE LOCATING PIN	2
22	DUP91347	BOLT M8*30	6
23	DUP100861481	CYLINDER HEAD GASKET	1
24	DUP100879889	INTAKE VALVE	1
25	DUP100879892	EXHAUST VALVE	1
26	DUP100879850	VALVE SPRING	2
27	DUP100882741	EXHAUST VALVE SPRING SEAT	1
28	DUP100938239	VALVE SEAL	1
29	DUP100882739	TOP CAP	1
30	DUP100879893	CYLINDER HEAD	1
31	DUP91359	BOLT M8X60	4
32	DUP100882815	CYLINDER HEAD LOCATING PIN	2
33	DUP100879901	ROCKING ARM SHAFT	2
34	DUP100879903	ROCKING ARM	2
35	DUP100879902	ROCKER SHAFT FIXING BRACKET	1
36	DUP91325	BOLT M6X12	8
37	DUP100861480	CYLINDER HEAD COVER GASKET	1
38	DUP100879881	CYLINDER HEAD COVER	1
39	DUP100942451	BOLT M6X16	8
40	DUP100861186	SPARK PLUG	1
41	DUP100883147	FLYWHEEL ASSEMBLY	1
42	DUP100882447	IMPELLER	1
43	DUP100882456	STARTER PULLEY	1
44	DUP90003	NUT M14*1.5	1
45	DUP100860803	IGNITER	1

No.	Part number	Description	Qty
46	DUP100879857	PANEL,RH	1
47	DUP100879897	SHROUD	1
48	DUP100879844	WIND-LEAD-COVER	1
49	DUP100879871-0001	RECOIL STARTER ASSEMBLY	1
50	DUP100861646	EXHAUST GASKET	1
51	DUP100879869	MUFFLER	1
52	DUP100938484	AIR EXHAUST STUD STUD BOLT	2
53	DUP100939068	SPRING WASHER	2
54	DUP90011	NUT M8	2
55	DUP100861479	INTAKE GASKET	1
56	DUP100879882	CARBURETOR CONNECTION BLOCK	1
57	DUP100861648	CARBURETOR GASKET	1
58	DUP100937619-0001	CARBURETOR ASSEMBLY	1
59	DUP100939087	STEEL WASHER	1
60	DUP100938501	DOUBLE END BOLT	2
61	DUP100937624-0001	FUEL TANK	1
62	DUP100879859	OIL DIPSTICK DECORATIVE PANEL	1
63	DUP100879866	SPRING C	1
64	DUP100879865	THROTTLE LEVER	1
65	DUP100860994	CHARGING COIL	1
66	DUP100879863	SPEED REGULATING ARM	1
67	DUP100883349	ENGINE SWITCH	1
68	DUP100879862	SPEED CONTROLLER	1
69	DUP100938016-0001	FUEL CAP	1
70	DUP92251	SCREW	1
71	DUP100937625-0001	DIPSTICK ASSEMBLY	1
72	DUP100938078-0009	OIL PLUG	2
73	DUP100879825	WIRING HARNESS	1
74	DUP100938336	METAL CLIP	1
75	DUP100939201	FUEL LINE CLAMP $\Phi 9$	2
76	DUP100860761	FUEL LINE	1
77	DUP100879858	FRONT DECORATIVE PANEL	1
78	DUP100861918	EXHAUST PIPE	1
79	DUP100879852	FUEL TANK RIGHT BRACKET FIXING PLATE	1
80	DUP100879868	SHIELD	1
81	DUP100879888	OIL SENSOR	1
82	DUP100879860	DECORATIVE BOARD	1
83	DUP100879853	FUEL TANK LEFT BRACKET FIXING PLATE	1
84	DUP100942459	BOLT M6X30	6
85	DUP100942466	BOLT M6*28	2
86	DUP100882473	SPEED PEGULATING HANDLE	1
87	DUP100879864	SPRING	1
88	DUP100863553	CRANKSHAFT FLAT KEY	1
89	DUP100879867	HEATING PIPE	1
90	DUP100882435	OIL PROTECTOR	1

No.	Part number	Description	Qty
91	DUP100863064	COIL	1
92	DUP100882742	INTAKE VALVE SPRING SEAT	1
93	DUP90017	NUT M6	5
94	DUP91386	BOLT M8×1×30	1
95	DUP100939130	FLAT WASHER Ø35×Ø8.4×4	1
96	DUP100862564	FIBERGLASS PIPE	1
97	DUP91327	BOLT M6×12	11
98	DUP100942447	BOLT M6×16	3
99	DUP91397	BOLT M6×20	1
100	DUP100860900	STARTING MOTOR ASSEMBLY	1
101	DUP100879861	CONTROL BOX INSTALLATION BRACKET	1
102	DUP91413	SCREW M4×55	2
103	DUP100938222	LOCATING PIN	2
104	DUP91322	BOLT M5*12	1
105	DUP100942457	BOLT M6*40	1