

DUCAR

Diagramme de pièces *Parts diagram*




Le modèle peut différer légèrement de la photo / *The model may differ slightly from the picture*

D2000iS

Moteur *Engine*

D2000iS



Spare parts for D2000iS Inverter engine

NO.	Code	Description	Qty
1	200201	CRANKCASE	1
2	205101	SWITCH ASSEMBLY,OIL LEVEL	1
3	91325	BOLT M6X12	7
4	209903	CLAMPER CORD	1
5	93501	OIL SEAL	2
6	93008	BALL BEARING	2
7	200301	CRANKSHAFT	1
8	201201	PISTON	1
9	201601	SCRAPER RING SET ,PISTON	1
10	205501	PIN, PISTON	1
11	201301	CLIP, PISTON	2
12	201501	ROD ASSEMBLY., CONNECTING	1
13	206101	LIFTER,VALVE	2
14	202001	CAMSHAFT ASSEMBLY	1
15	240904	CRANKCASE, PIN, DOWEL	4
16	96004	GASKET,MOULD ASSEMBLING	1
17	200101	COVER ASSEMBLY, CRANKCASE	1
18	205601	DIPSTICK	1
19	96005	GASKET,CYLINDER HEAD	1
20	201001	CYLINDER HEAD	1
21	94407	CLIP,BREATHER TUBE ϕ 10.5	2
22	201901	ROD,PUSH	2
23	97502	MAGNETO IGNITION	1
24	209901	STRIPPER RUBBER	1
25	91330	BOLT M6X20	7
26	200401	FLYWHEEL	1
27	90014	NUT, FLYWHEEL M12	1
28	204701	RECOIL STARTER ASSEMBLY	1
29	91805	CROSS RECESSED PAN HEAD BOLTS	2
30	91329	BOLT M6X16	12
31	202301	THERMAL INSULATION,CARBURATOR	1
32	96121	PAPER WASHER,CARBURATOR	1
33	202801	CARBURETOR ASSEMBLY	1
34	94217	FLAT WASHER ϕ 3.2	2
35	94203	SPRING WASHER ϕ 3.2	2
36	209906	STEPPER MOTOR PROTECTIVE COVER	1
37	96009	GASKET,AIR CLEANER	1
38	202901	AIR CLEANER ASSEMBLY	1
38.1	5138	ELEMENT,AIR CLEANER	1
38.2	5034		1
38.3	5188	COVER, AIR CLEANER	1
38.4	5190		1
39	90016	NUT M6	4
40	752007	STEPPER MOTOR	1
41	95614	TUBE,BREATHER	1

42	202502	MUFFLER COVER2	1
43	209902	CLIP,MUFFLER COVER	1
44	203701	MUFFLER ASSY	1
45	97501	IGNITION COIL	1
46	96008	GASKET,EXHAUST	1
47	202102	EXHAUST VALVE ROCKER ASSY	1
48	202103	ROCKSHAFT	1
49	202101	INLET VALVE ROCKER ASSY	1
50	91339	BOLT M6X50	4
51	205901	VALVE EXHAUST	1
52	201701	VALVE,IN	1
53	201802	INLET VALVE SPRING SEAT	1
54	206001	SPRING,VALVE	2
55	201801	SEAT, VALVE SPRING,IN	2
56	200801	VALVE LOCK CLAMP	2
57	200501	SHROUD	1
58	96006	PACKING,HEADCOVER	1
59	201103	CYLINDER COVER BREATH BOARD	1
60	201104	BREATH BOARD SEALING GASKET	1
61	201101	COVER COMP,CYLINDER HEAD	1
62	91002	BOLT, STUD M6X32	2
63	96007	GASKET,CONNECTION BLOCK	1
64	91023	BOLT, STUD M6X92	2
65	97101	SPARK PULG	1