

DUCAR

Diagramme de pièces *Parts diagram*




Le modèle peut différer légèrement de la photo / *The model may differ slightly from the picture*

DG1500

Génératrice

Generator

DG1500



Spare parts for the DG1500 generator			
NO.	Code	Part name	quantity
1	773430-010	Frame	1
2	531102	Isolator A	1
3	90011	Nut M8 M8	6
4	531112	Rubber Damping Bracket	4
5	91325	Bolt M6X12	5
6	700113-026	Fuel Tank Assembly	1
6,1	6189	FUEL TANK CAP COMP	1
6,2	6169	FUEL FILTER	1
7	518104	Fuel Cock	1
9	94002	TOOTH TYPE GASKET $\Phi 6$	1
10	91343	Bolt M8X16	2
11	751405	motor assembly	1
11,1	599020	carbon brush comp	1
11,2	6079	grounding post comp	1
12	532102	motor stand	1
13	91703	Bolt	1
14	96812	GASKET, ROTOR BOLT $\Phi 8.5 \times \Phi 24 \times 3$	1
15	95902	TUBE,BREATHER	1
16	91603	Bolt	4
17	531106	ISOLATOR B	2
18	531103	ISOLATOR B	1
19	90018	Nut M8	2
20	91305	Bolt M6X20	4
21	705113	Muffler COMP	1
22	96033	Packing,exhaust	1
23	713460	panel comp	1
23,1	305201	SWITCH ASSEMBLY	1
23,2	6058	TIME ACCUMULATOR CSA	1
23,3	6277	CIRCUIT BREAKER 12A/1P/30 CSA	1
23,4	6204	DOUBLE RECEPTACLE,AMERICA	1
23,5	599923	THERMAL PROTECTOR 8A/CSA	1
24	599302	CLIP $\Phi 12$	2
25	534105	Automatic Voltage Regulator	1
26	91322	Bolt M5X12	7
27	91323	Bolt M5X16	1
28	96811	Washer, Fuel Tank	4
29	91329	Bolt M6X16	4
30	533104-026	End Cover,Generator	1
31	94206	SPRING WASHER $\Phi 8$	2
32	544301	FRAME WIRE	1
33	90016	Nut M6	1
34	245405	ROLL OVER VALVE	1
35	95311	CONNECTING PIPE	1
36	210801	CLIP	1
37	94408	CLIP,FUEL LINE $\Phi 10$	1
38	94409	CLIP,FUEL LINE $\Phi 9.5$	1
39	94403	CLIP,FUEL LINE $\Phi 7.5$	1
40	94204	SPRING WASHER $\Phi 5$	1
41	94001	TOOTH TYPE GASKET $\Phi 5$	1