

DUCAR

Diagramme de pièces *Parts diagram*




Le modèle peut différer légèrement de la photo / *The model may differ slightly from the picture*

DP80

Moteur

Engine

DP80



Spare parts for the DP80 gasoline engine

NO.	Code	Description	Quantity
1	240210	CRANKCASE	1
2	93009	BALL BEARING	2
3	93507	OIL SEAL	2
4	244302	GOVERNOR ASSEMBLY	1
5	243901	SHAFT,GOVERNOR ARM	1
6	96804	WASHER,GOVERNOR ARM SHAFT	1
7	243902	PIN,LOCK	1
8	91816	BOLT, DRAIN PLUG	2
9	94007	WASHER,DRAIN PLUG	2
10	240901	DOWEL PIN,CASECOVER	2
11	241208	PISTON	1
12	241606	SCRAPER RING SET ,PISTON	1
13	241503	ROD ASSEMBLY., CONNECTING	1
14	245503	PIN, PISTON	1
15	241301	CLIP, PISTON	2
16	240104	COVER ASSEMBLY, CRANKCASE	1
17	241401	OIL PLUG	1
18	245601	DIPSTICK	1
19	241011	CYLINDER HEAD	1
20	241704	VALVE,IN	1
21	245904	VALVE EXHAUST	1
22	241806	RETURNER,INTAKE VALVE	1
23	246001	SPRING,VALVE	2
24	241801	SEAT, VALVE SPRING,IN	1
25	241802	SEAT, VALVE SPRING,EX	1
26	242202	PLATE,PUSH ROD GUIDE	1
27	91818	ROCKER ARM TIGHTENING BOLTS	2
28	241804	ROTATOR	1
29	91006	BOLT, STUD	2
30	91007	BOLT, STUD	2
31	242816	CARBURETOR ASSEMBLY	1
32	95405	FUEL LINE	1
33	94408	CLIP,FUEL LINE	1
34	244001	GOVERNOR ARM	1
35	91822	BOLT,GOVERNOR ARM	1
36	90016	NUT M6	5
37	240345	CRANKSHAFT ASSEMBLY	1
38	246102	LIFTER,VALVE	2
39	96041	PACKING,CASECOVER	1
40	242003	CAMSHAFT ASSEMBLY	1
41	240905	PIN, DOWEL	2
42	91347	BOLT M8X30	6
43	96058	GASKET,CYLINDER HEAD	1
44	91359	BOLT M8X60	4
45	97108	SPARK PULG	1
46	241901	ROD,PUSH	2
47	240501	SHROUD	1
48	91325	BOLT M6X12	13
49	96045	PACKING,HEADCOVER	1
50	241107	COVER COMP,CYLINDER HEAD	1
51	245702	WIND SHIEL COMP.	1
52	91330	BOLT M6X20	1
53	240401	FLYWHEEL ASSEMBLY	1

Spare parts for the DP80 gasoline engine

NO.	Code	Description	Quantity
54	244601	FAN,RECOIL STARTER	1
55	244502	PULLEY,STARTER	1
56	90003	NUT	1
57	97514	IGNITION COIL ASSY	1
58	91331	BOLT M6X25	3
59	96047	PACKING,INTAKE	1
60	242301	INSULATOR,CARBURETOR	1
61	96051	PACKING,CARBURETOR	1
62	94226	SPACER,CARBURETOR	1
63	242701	ROD,GOVERNOR	1
64	244201	SPRING,THROTTLE RETURN	1
65	244740-026	RECOIL STARTER ASSEMBLY	1
66	245205	SWITCH ASSEMBLY	1
67	244401	SHROUD ASSY,UPPER	1
68	242937	AIR CLEANER ASSEMBLY	1
68,1	5208	COVER, AIR CLEANER	1
68,2	5209	ELEMENT,AIR CLEANER	1
68,3	5210	BOTTOM COVER,AIR CLEANER	1
69	244101	SPRING,GOVERNOR	1
70	94404	CLIP,FUEL LINE	2
71	96054	PACKING,EXHAUST	1
72	243737	MUFFLER COMP	1
73	90011	NUT M8	2
74	94206	SPRING WASHER	2
75	243126-026	FUEL TANK ASSEMBLY	1
75,1	5121	FUEL FILTER	1
76	519201	FUEL TANK CAP COMP	1
77	95302	CONNECTING PIPE	1
78	245405	MANUAL CHOKE ASSEMBLY	1
79	91329	BOLT M6X16	2
80	242101	ROCKER ARM	2
81	95903	VENTILATION TUBE PROTECTOR	1
82	240801	CLIP	1
83	95603	TUBE,BREATHER	1
84	599601	CLIP,WIRE HARNESS	1
85	94409	CLIP,FUEL LINE	1
86	245102	SWITCH ASSEMBLY,OIL LEVEL	1
87	245104	AMPLIFIER	1