

DUCAR

Diagramme de pièces *Parts diagram*




Le modèle peut différer légèrement de la photo / *The model may differ slightly from the picture*

DT36V-6

Moteur *Engine*

DT36V-6



Spare parts for the DT36V-6 gasoline engine			
NO.	Code	Description	Qty
1	91365	BOLT M6X12	7
2	311102	COVER COMP,CYLINDER HEAD	1
3	96161	PACKING,HEADCOVER	1
4	242101	ARM, ROCKER	2
5	312201	PLATE,PUSH ROD GUIDE	1
6	311802	SEAT, VALVE SPRING,IN	2
7	316001	SPRING,VALVE	2
8	311801	RETURNER,INTAKE VALVE	2
9	311701	VALVE, INTAKE	1
10	315901	VALVE EXHAUST	1
11	97108	SPARK PULG	1
12	314701-026	COVER,RECOIL	1
13	91369	BOLT M6X25	1
14	310502	BRAKE ASSY.	1
15	314302	PLATE,GOVERNOR	1
16	311901	ROD,PUSH	2
17	316101	LIFTER,VALVE	2
18	312001	CAMSHAFT ASSY	1
19	311602	SCRAPER RING SET ,PISTON	1
20	311201	PISTON	1
21	315501	PIN, PISTON	1
22	291301	CLIP, PISTON	2
23	311501	ROD ASSEMBLY., CONNECTING	1
24	310202	CYLINDER	1
25	93524	OIL SEAL	1
26	90043	NUT,FLANGE	3
27	91829	Adjuster Rocker Arm	2
28	310501	SHROUD	1
29	599601	THE METAL CLIP	1
30	310604	BOLT WITH DISC M6X8	1
31	296507	THE CRANKSHAFT FLAT KEY	1
32	91038	BOLT, STUD	2
33	293607	FUEL TANK CAP COMP	1
34	313102	FUEL TANK	1
35	91399	BOLT M6X38	1
36	313401	BUSHING,FUEL TANK	1
37	91370	BOLT M6X16	4
38	300605	CIRCULAR PLATE	1
39	94417	CLIP,FUEL LINE	1
40	95497	FUEL LINE	1
41	313901	SHAFT,GOVERNOR ARM	1
42	96808	WASHER,GOVERNOR ARM SHAFT	1
43	93520	SEAL,GOVERNOR ARM SHAFT	1
44	243902	PIN,LOCK	1

45	314001	GOVERNOR ARM	1
46	91822	BOLT,GOVERNOR ARM	1
47	90016	NUT M6	3
48	312701	ROD,GOVERNOR	1
49	314201	SPRING,THROTTLE RETURN	1
50	314104	SPRING,GOVERNOR	1
51	90036	NUT	2
52	314402	SHROUD ASSY,UPPER	1
53	95626	TUBE,BREATHER	1
54	94403	CLIP,FUEL LINE	1
55	310303	CRANKSHAFT ASSY	1
56	90037	NUT	2
57	94225	WASHER,CRANKSHAFT	1
58	314303	GOVERNOR ASSEMBLY	1
59	96162	GASKET,BREATHER CHAMBER	1
60	310602	CAP,BREATHER CHAMBER	1
61	310901	DOWEL PIN,CASECOVER	2
62	310102	COVER ASSEMBLY, CRANKCASE	1
63	93523	OIL SEAL	1
64	91366	BOLT M6X18	6
65	91367	BOLT M6X45	2
66	94435	CLAMP,BREATHER TUBE	1
67	310606	BREATHING VALVE SPRING	1
68	315601-053	DIPSTICK	1
69	90038	NUT M6	2
70	310608	FILTER,BREATHER	1
71	97565	IGNITION COIL ASSY	1
72	91040	BOLT STUD,IGNITION COIL	1
73	91041	BOLT STUD,RECOIL STARTER	2
74	310403	FLYWHEEL ASSEMBLY	1
75	304602	FAN,RECOIL STARTER	1
76	314501	PULLEY,STARTER	1
77	90003	NUT	1
78	312502	SHIELD, MUFFLER	1
79	96130	GASKET,AIR CLEANER	1
80	292914	AIR CLEANER ASSEMBLY	1
81	91039	BOLT, STUD	2
82	96128	PACKING,INTAKE	1
83	312301	INSULATOR,CARBURETOR	1
84	96129	PACKING,CARBURETOR	1
85	312806	CARBURETOR ASSY	1
86	96131	GASKET,EXHAUST	1
87	313703	MUFFLER ASSY	1
88	316403	FLAMEOUT WIRE	1
89	296402	FLAMEOUT WIRE	1
90	299901	FILTER	1